

Network Camera

User Manual

V1.05

Contents

About This Manual.....	1
1 Defaults.....	2
2 Login.....	2
3 Initial Configuration.....	3
4 Live View.....	5
5 Playback.....	9
5.1 Playback Toolbar.....	10
5.2 Search and Playback.....	10
5.3 Recording Download.....	11
6 Photo.....	11
7 Setup.....	13
7.1 Common.....	13
7.1.1 Basic Info.....	13
7.1.2 Network.....	14
7.1.3 Time.....	15
7.1.4 OSD.....	17
7.1.5 External Device.....	20
7.1.6 Vehicle List.....	21
7.1.7 Vehicle Release Configuration.....	23
7.1.8 Platform Access.....	25
7.1.9 Smart.....	30
7.2 System.....	34
7.2.1 Time.....	34
7.2.2 User.....	34
7.2.3 Log.....	37
7.2.4 Device Info.....	37
7.3 Network.....	38
7.3.1 Basic Config.....	38
7.3.2 Service Config.....	41
7.3.3 Platform Access.....	44
7.3.4 Dual-Camera Parameters.....	45
7.4 Security.....	46
7.4.1 Network Security.....	46
7.4.2 Video Security.....	48
7.4.3 Access Policy.....	49
7.4.4 Certificate Management.....	50
7.4.5 Registration Info.....	52
7.5 Image.....	53
7.5.1 Image.....	53

7.5.2 OSD.....	60
7.5.3 Privacy Mask.....	61
7.6 Video & Audio.....	61
7.6.1 Video.....	61
7.6.2 ROI.....	63
7.6.3 Audio.....	63
7.6.4 Media Stream.....	65
7.7 Event.....	66
7.7.1 Common Alarm.....	66
7.8 Storage.....	73
7.8.1 Storage.....	75
7.8.2 FTP.....	76
8 Maintenance.....	78
8.1 Maintenance.....	78
8.1.1 Maintenance.....	78
8.1.2 Network Diagnosis.....	79

About This Manual

This manual describes the features and operations of entrance & exit bullet LPC.

Copyright Statement

2025-2026 Zhejiang Uniview Technologies Co., Ltd. All rights reserved.

No part of this manual may be copied, reproduced, translated or distributed in any form or by any means without prior consent in writing from Zhejiang Uniview Technologies Co., Ltd (hereinafter referred to as Uniview or us).

The product described in this manual may contain proprietary software owned by our company and its possible licensors. Unless permitted by its licensors, no one is allowed to copy, distribute, modify, abstract, decompile, disassemble, decrypt, reverse engineer, rent, transfer, or sublicense the software in any form by any means.

Applicable Models

This manual is applicable to the following models:

- PKC5601-C4Z-LED44-WH
- PKC5601-C4Z-LED44-IR
- PKC2841-Z28-WH
- PKC2841-Z28-IR
- PKC2650S-Z28-IR-P
- PKC2650S-Z28-WH-P
- PKC1540-Z28-P

Disclaimer

Due to such reasons as product version upgrade or regulatory requirement of relevant regions, this manual will be periodically updated.

This manual is for reference only, and all statements, information, and recommendations in this manual are presented without warranty of any kind. The figures, tables, or images in this manual are for reference only and may vary depending on the model.

The symbols in the following table may be found in this manual. Carefully follow the instructions indicated by the symbols to avoid hazardous situations and use the product properly.

Symbo	Description
	NOTE! Indicates useful or supplemental information about the use of product.
	CAUTION! Indicates a situation which, if not avoided, could result in damage, data loss or malfunction to product.
	WARNING! Indicates a hazardous situation which, if not avoided, could result in bodily injury or death.

1 Defaults

Username: admin	Password: 123456
Static IP address: 192.168.1.13	Subnet mask: 255.255.255.0

 **Note:** DHCP (Dynamic Host Configuration Protocol) is enabled by default. If a DHCP server is deployed in the network, the device may be assigned an IP address, and you need to use the assigned IP address to log in.


2 Login

Check Before Login

- The device runs normally.
- The client computer (hereinafter referred to as "client") is on the same network segment as the device and is connected to the network.

Log in to Web

1. Open a browser, enter the device's IP address (default: **192.168.1.13**) in the address bar, press **Enter**, and the login page appears.



2. Enter the username and password (**admin/123456** by default).
3. Click **Login**.
4. (For first-time login) Please follow the on-screen instructions to change the password into a strong one and set your email address, which can receive a security code if you forgot the password. Then, use the new password to log in again.

Forgot Password


If you forgot the password after changing it, you can obtain the security code to reset the password.

 **Note:** To use this function, make sure the device has an email address reserved, otherwise contact the local technical support to reset the password.

1. Click **Forgot Password** on the login page, and the **Retrieve Password** page appears.

Please scan the QR code to obtain the security code (for admin only):

- Scan with APP



We will send the security code to:
The administrator hasn't set linked email.
Please contact your supplier or Uniview for assistance.

Cancel Next

2. Follow the on-screen prompt to obtain a security code.
3. Enter the security code, and click **Next** to retrieve the password. Please note this new password.

Logout

Click **Logout** in the upper-right corner of the interface, and click **OK** to log out from the current user.

Download Plugin

If the plugin has not been downloaded, click  in the upper-right corner to download and install it. Otherwise, you cannot view the live view.

Logout

In the upper-right corner of the page, select ... > **Logout**. After confirming, you can log out.

Basic Info

In the upper-right corner of the page, select ... > **Basic Info** to quickly jump to the basic info content.

3 Initial Configuration

After your first login, follow the steps below to complete the basic setup.



Note: This manual applies to multiple camera models, and functions may vary between different models. This chapter lists all available functions. Please refer to the web interface of your device and skip any functions that are not applicable.

1. Change Password

By default, the username is admin and the password is 123456.

After your first login, you are forcibly to change the password into a strong one. Please note the new password.

2. Set IP Address

The IP address is 192.168.1.13 by default. You need to change the IP address to the one you want.

1. On the live view page, click  under the **Basic Config** tab.

Edit [X]

IPv4

Obtain IP Address: Static

IP Address: [Input Field]

Subnet Mask: [Input Field]

Default Gateway: [Input Field]

[Cancel] [OK]

2. Select **Static** from the **Obtain IP Address** drop-down list.
3. Enter the IP address, subnet mask, and gateway.
4. Click **OK**.

3. Draw Detection Box

After you log in to the camera's web interface for the first time, please follow the on-screen instructions to configure the initial parameters, or click **Setup Wizard** on the live view page.

1. Confirm the version information, and click **OK** or **Next** to proceed.

Setup Wizard [X]

1 Confirmation | Confirmation

SoftWare Version: [Blurred Text]

2 Recognition

3 Finish

[Next]

2. Refer to the example to draw the detection box. The camera takes a snapshot when the vehicle head enters the blue detection area.

- (1) Park a vehicle at the capture point and adjust the camera's shooting angle.
- (2) Click +/- or enter the value in the **Zoom** box to adjust the zoom ratio.

[+] Zoom [-]

- (3) Click +/- to adjust the focus for clear license plate image.

[+] Focus [-]

- (4) Draw a blue detection box. It should be in the lower half of the live view. The top edge of the detection box must be horizontal. The bottom edge should ideally remain horizontal. Both sides must cover the left and right boundaries of the lane. The area should occupy 1/3 of the live view page.

Click the blue box and drag the vertexes to adjust the size when white rectangles appear at all four corners.

Click **Save** to save the drawing, or click **Cancel** to reset.

- (5) Move the red detection box. The size must approximate that of a standard license plate.

Click the red box and drag it when white rectangles appear at all four corners.

(6) (Optional) There is a default angle. You can click **Reset** to restore it.

3. Click **Next** and confirm again.

4. Configure Recognition Parameters

Configure the basic parameters on the live view page.

Basic Config

IP Address 

Trigger Mode Trigger by Video ▼

Detection Region Common ▼

Movement Direction Both ▼

- Trigger Mode


Trigger Mode	Description
Trigger by Video	(Recommended) Used for scenarios without external devices. The camera takes a snapshot when the vehicle head enters the blue detection area.
Trigger by Loop	Used for scenarios with external devices (such as loops, radar). When the external device detects a vehicle, it send signals to the camera for vehicle capture and recognition.

- Detection Region: Change to the region where the camera is located.
- Movement Direction

Direction	Description
Both	(Recommend) Capture vehicles entering the detection area from the top/bottom of the live view.
Upward	Only capture vehicles entering the detection area from the top of the live view.
Downward	Only capture vehicles entering the detection area from the bottom of the live view.

4 Live View

After login, the **Live View** page appears by default.



Live View Window

- Left pane: Show the live video.
- Right upper pane: Show the thumbnail image of the latest captured license plate.
 **Note:** Please enable **Generate Color Photo** at [Intelligent Configuration](#).
- Right lower pane: Show the complete image of the latest captured license plate.

Live View Toolbar

Button	Description
	Start/stop live view.
	Start/stop local recording.  Note: This feature is not supported when live video is paused.
	Take a snapshot.  Note: This feature is not supported when live video is paused.
	Start digital zoom. Click on the area you want to zoom in, then use your scroll wheel to zoom in/out. Click  to exit digital zoom.
	Click to show  , and you can adjust the output and input volume.  Note: • To use this function, connect the audio input and output devices to your computer. • If the camera's audio input is enabled, the recording function will be unavailable when the plug-in is not installed. Please disable Audio.
	Take a snapshot from the displayed live video. See the snapshot in Photo .
Overlay Recognition Frame	When selected, the live view page will show one detection area. You can adjust the area as needed. See 3. Draw Detection Box for details.

Snapshot Recognition Result

Snapshot Recognition Result										
Total Vehicle:80 Unlicensed Vehicle:2 Clear Vehicle ...										
No.	Snapshot Time	Vehicl...	Vehicl...	Plate C...	Plate N...	Trigger...	List Type	Plate ...	Event ...	Direction
1	2026-07-13 11:13:14.532	Unknown	Unknown	Blue		Debug Snapshot	Temporary Vehicle	0	Plate Recognition	Downward
2	2026-07-13 11:13:22.005	Unknown	Unknown	Blue		Debug Snapshot	Temporary Vehicle	0	Plate Recognition	Downward

The list shows the captured results in chronological order from top to bottom. The list data will be automatically cleared if you open another page.

Click any result, and the small image and the complete image of the license plate will be displayed on the right windows respectively.

Click **Clear Vehicle List** to clear the snapshot records in the list.

View the historical snapshots in [Photo](#).

The following describes the certain fields:

Parameter	Description
List Type	- If the plate number exists in the allowlist and the vehicle passing time is within the validity period, the list type will be Allowlist. - If the plate number exists in the blocklist and the vehicle passing time is within the validity period, the list type will be Blocklist. - If the plate number is absent from both allowlist and blocklist, or the vehicle passing time is not within the validity period, the list type will be Temporary Vehicle. - If the plate number exists in both allowlist and blocklist and the vehicle passing time is within validity period, the list type will be Blocklist.  Note: You can configure the allowlist and blacklist at Vehicle List.
Plate Width	It is displayed when a vehicle with a plate is captured.  Note: Please enable Generate Color Photo at Intelligent Configuration before use; otherwise, the plate width is 0.

Device Info

Device Info

Firmware Version



Algorithm Version ...



Cloud Upgrade

Cloud Upgrade

You can view the current software version and algorithm version.

The software version can be upgraded in [Maintenance](#).

Cloud Upgrade: Click to perform a version check. If the latest version is available on the cloud server, you can perform the upgrade.

Setup Wizard

Click to redraw the detection box. See [3. Draw Detection Box](#) in initial configuration.

Camera Control

| Camera Control

+	Zoom	-
---	------	---

+	Focus	-
---	-------	---

- Zoom: Zoom in or out on images.
- Focus: Focus far or near for clear images.

Basic Config

For IP address setting, see [2. Set IP Address](#).

For other parameter settings, see [4. Configure Recognition Parameters](#).

Advanced Config

| Advanced

LPR Pixel Range ~

Identify Deceptive ... ☐

Unlicensed-Car S... ☒

Vehicle Overstay ... ☐

Motorcycle Detecti... ☐

Vehicle Reverse D... ☐

Vehicle Overstay ... s

- LPR Pixel Range: The license plate number can be identified if the plate pixel is within the set range; otherwise, the vehicle will be recognized as a vehicle with no plate.

The default pixel range is suitable for most scenarios. This range is recommended unless there are specific requirements.

When the trigger mode is **Trigger by Video**, the detected plate pixels will be displayed on the live video; otherwise, the pixels will not be displayed.
- Identify Deceptive License Plate: Can filter most deceptive license plates, such as license plate photos and paper-printed license plates.
- Unlicensed-Car Snapshot: When enabled, no-plate vehicles can be captured and records generated; when disabled, no-plate vehicles are not captured and no records are generated. Configure according to actual on-site requirements.
- Vehicle Overstay Detection
 - On: You need to set **Vehicle Overstay Threshold** first.

The camera continuously detects motor vehicles that have been captured and are staying within the overlaid recognition area. When the set time is exceeded, a vehicle overstay alarm record will be generated; when the vehicle leaves the detection area, a vehicle overstay alarm cleared record will be generated.
 - Off: The camera cannot detect and alarm vehicle overstay behavior.
- Vehicle Reverse Detection: When a vehicle reverses out of the view, the camera will generate a vehicle reverse alarm record.
- Generate Vehicle Pass-thru Records Without Recognition: Vehicle passing records are generated directly without identifying vehicles.

- Vehicle Characteristics Recognition: When enabled, the vehicle characteristics will be recognized, including vehicle model, brand, logo, and color, and overlaid on the vehicle's composite photo along with OSD.
- Motorcycle Detection: When enabled, the motorcycles can be recognized.

Indicator Description


Type/ Indicator			
Intelligent Server 1/2	Please set it in Intelligent Platform .		
	The server is connected and online.	The server is disconnected or offline.	/
Edge Storage	Please set it in Storage .		
	The Micro SD card has been installed and is normal.	/	No Micro SD card is installed.
Internet Connection	The camera is connected to the network.	The camera is disconnected from the network.	/
MQTT Server	The server is connected and online.	The server is disconnected or offline.	/
LED	Enable Smart Illumination in Image to turn on the illuminator	/	Illuminator is turned off

5 Playback



Note:

- Edge recordings refer to video recorded on storage media of cameras; local recordings refer to video recorded on a local PC.
- Before you search for edge recordings, make sure that the camera has an installed Micro SD card, and [Storage](#) is properly configured.
- Recording playback and download functions are only available on certain models.
- For dual-channel devices, you can set playback parameters for the channels separately.

Enter the playback page.



5.1 Playback Toolbar

Button	Description
	Adjust sound volume. Range: 0 to 100.
	Start playback.
	Pause playback. Click  to resume the playback.
	Exit the playback.
	Start/stop clipping video. You can download the video clips to your computer.
	Download recordings in batches.
	Adjust the playback speed. The default speed is 1x. 2x plays faster, and 1/2x plays slower. -2x rewinds fast.
	Take a snapshot. The snapshots are saved locally by default.
	Enable digital zoom. Click on the area you want to zoom in, then use your scroll wheel to zoom in. Right-click to restore to its original size. Click  to exit digital zoom.
	Zoom in/zoom out on the time scale. You can also use the scroll wheel to zoom.
	Playhead. Drag the playhead to skip to any point in the video.
	Playback timeline, including two colors: - Blue: Normal recording. - Red: Alarm recording. To view alarm recordings, you need to configure alarm-triggered recording.

5.2 Search and Playback

 **Note:** Certain cameras support simultaneous playback on two clients.

1. For a multi-channel camera, select the channel first.
2. Select the recording type.
3. Select the date on the calendar.
4. Click **Search**.
5. Select the desired recording from the search results. Click the corresponding  to start playback. Click  to stop playback; click  to pause playback.


 **Note:** If the results contain 10 recordings and playback starts from the 3rd recording, and 2 new recordings are added during playback, then the system will then play recordings 3 through 12.

5.3 Recording Download

You can download videos in batches or clip videos to download.

Download in Batches

1. Click .
2. Select the recording type.
3. Set the start time and end time.
4. Click **Search**, search results are displayed.




The dialog box titled "Recording Download" contains a "Recording Type" dropdown menu set to "All Recordings" and a "Recording Time" range from "2026-05-28" to "2026-05-28" with a calendar icon. A "Query" button is to the right. Below is a table with columns: checkbox, No., Start Time, and End Time. The table lists five recordings. At the bottom are "Cancel" and "Download" buttons.

☐	No.	Start Time	End Time
☐	1	2026-05-28 11:34:30	2026-05-28 11:56:48
☐	2	2026-05-28 11:56:48	2026-05-28 12:19:07
☐	3	2026-05-28 12:19:07	2026-05-28 12:41:25
☐	4	2026-05-28 12:41:25	2026-05-28 13:03:43
☐	5	2026-05-28 13:03:43	2026-05-28 13:26:02

5. Select the checkboxes for the recordings you want to download and click **Download**.

Download Video Clips

1. Refer to [Search and Playback](#) to search for and play the recording you want to clip and download.
2. On the playback toolbar, click .
3. Drag both ends of  to select the start and end time.
4. Click .
5. Select the checkboxes for the recording(s) you want to download, and then click **Download** to save the recordings from the storage resource to your local device.

6 Photo

This page shows all the captured license plate information.

Enter the **Photo** page.

Plate Number

Snapshot Time
2026-07-13 00:00:00 ~ 2026-07-13 23:59:59

Vehicle Type
All

Vehicle Color
All

Event Type
All

Plate Color
All

Query

Reset

Export All Records
Export Selected Image(s)
Export All Images

☐	No.	Plate Num...	Snapshot ...	List Type	Plate Color	Identify Ve...	Event Type	Vehicle Type	Plate Widt...	Trigger Mo...	Direction	Detection ...	Operation
☐	1	Unlicensed Vehicle	2026-07-13 13:12:42	Temporary Vehicle	Unknown	Unknown	Plate Recognition	Motorcycle	0	Video Detection	Downward	Unknown	+
☐	2	Unlicensed Vehicle	2026-07-13 13:11:04	Temporary Vehicle	Unknown	Unknown	Plate Recognition	Motorcycle	0	Video Detection	Unknown	Unknown	+
☐	3	Unlicensed Vehicle	2026-07-13 13:05:21	Temporary Vehicle	Unknown	Unknown	Plate Recognition	Motorcycle	0	Video Detection	Downward	Unknown	+
☐	4	Unlicensed Vehicle	2026-07-13 12:43:07	Temporary Vehicle	Unknown	Unknown	Plate Recognition	Motorcycle	0	Video Detection	Downward	Unknown	+
☐	5	Unlicensed Vehicle	2026-07-13 12:31:43	Temporary Vehicle	Unknown	Unknown	Plate Recognition	Motorcycle	0	Video Detection	Downward	Unknown	+
☐	6	Unlicensed Vehicle	2026-07-13 12:26:49	Temporary Vehicle	Unknown	Unknown	Plate Recognition	Motorcycle	0	Video Detection	Unknown	Unknown	+

Total: 89
1 2 3 4 5 ... 9 > Go To 1

Search

You can filter the results using the criteria listed above.

View Snapshot Image

Click the corresponding for the snapshot record, and the snapshot image will appear on the list above.

Add to Vehicle List

Click + to add the recognized vehicle information to the allowlist or blocklist.

Add to Vehicle List

Detection Mode
☒ Allowlist
☐ Blocklist

Status
☒

Plate Number

Start Time

End Time

Remarks

Note: An empty end time means long-term validity.

Cancel

OK

Export

- Export All Records: Click **Export All Records** and click **OK**.
- Export Selected Images: Select the record(s) you want to export, and click **Export Selected Image(s)**.
- Export All Images: Click **Export All Images** and click **OK**.

7 Setup

7.1 Common

7.1.1 Basic Info

7.1.1.1 Basic Info

View the basic information and operation status of the device.

You can view the camera's basic parameters and view the real-time operation status, thereby improving the camera's maintainability.

Go to **Setup > Common > Basic Info > Basic Info**.

Basic Info

Model	XXXXXXXXXX-XXXX-XXXX
IPv4 Network Info	192.168.1.100/24 192.168.1.101/24 192.168.1.102/24
IPv6 Network Info	2001:0000:XXXX:XXXX::0000
MAC Address	20:26:06:16:13:57

Version Info

Firmware Version	XXXXXXXXXX-XXXX-XXXX
Hardware Version	A
Boot Version	V4.0
Serial No.	XXXXXXXXXX-XXXX-XXXX

Status

System Time	2026/7/13 13:46:27
Operation Time	5 Day(s) 3 Hour(s) 50 Minute(s)

Refresh

- Basic Info: View the device model, firmware version, hardware version, etc.
- Status: View the system time and device operation time. Click **Refresh** to update the data.

7.1.1.2 Open Source Software Licenses

Go to **Setup > Common > Basic Info > Open Source Software Licenses**.

Open Source Software Licenses

Click **Open Source Software Licenses** to view details.

7.1.2 Network

1. Go to **Setup > Common > Network**.

IPv4

Obtain IP Address:

IP Address:

Subnet Mask:

Default Gateway:

IPv6

Mode:

Address:

Prefix Length:

Default Gateway:

Basic

MTU:

Port Type:

Save

2. Configure the network parameters.



Note: Some devices have two network interfaces, allowing separate configurations for interface 1 and interface 2.

- **IPv4**

- **Manual**

- (1) Select **Manual** from the **Obtain IP Address** drop-down list.
- (2) Enter the IP address, subnet mask, and default gateway. Make sure that the IP address of the camera is unique in the network.
- (3) Click **Save**.

- **PPPoE**

Configure PPPoE to assign a dynamic IP address.

- (1) Select **PPPoE** from the **Obtain IP Address** drop-down list.
- (2) Enter the username and password provided by your ISP (Internet Service Provider), click **Save**, then the camera will be assigned an IP address.

- **Obtain Automatically (DHCP)**

DHCP (Dynamic Host Configuration Protocol) is enabled by default. If a DHCP server is deployed in the network, the camera can automatically obtain an IP address from the DHCP server.

- (1) Select **Obtain Automatically (DHCP)** from the **Obtain IP Address** drop-down list.
- (2) Complete the settings as shown below.

IPv4

Obtain IP Address: Obtain Automatically (DHCP) ▼

IP Address: [Input field]

Subnet Mask: [Input field]

Default Gateway: [Input field]

- IPv6

- **Obtain Automatically (DHCP)**

The default mode is **Obtain Automatically(DHCP)**. In this mode, the IP address is assigned by the DHCP server.

- Manual

(1) Select **Manual** from the **Mode** drop-down list.

(2) Enter the IPv6 address, prefix length, and default gateway. Make sure that the IPv6 address is unique in the network.

3. Set the basic parameters.

- MTU: Set the maximum packet size supported by the network in bytes. The greater the value, the higher the communication efficiency, the higher the transmission delay.
- Port Type: **FE Port** by default.
- Operating Mode: **Auto-negotiation** by default.

Basic

MTU: 1500

Port Type: FE Port ▼

Operating Mode: Auto-negotiation ▼

4. Click **Save**.

7.1.3 Time

7.1.3.1 Time

Set the camera time.

1. Go to **Setup > Common > Time > Time**.

Sync Mode: Sync with Latest Server Time ▼

Time Zone: (UTC+08:00) Beijing, Hong Kong, Urumqi, ... ▼

System Time: 2026-07-13 13:53:05 [Calendar icon] Sync with Computer Time

NTP Server

NTP Server Address: 10.1.1.1 Test

Port: 123

Update Interval(s): 600

Save

2. You can set the device time manually or sync it with a server.

- Set manually: Set the system time as needed.

 **Note:** Make sure **Sync Mode** is set to **Sync with System Configuration**; otherwise, the device time will still sync with other sources after you set it manually.

- Sync time automatically:

(1) Select the sync mode.

Parameter	Description
Sync with System Configuration	The device uses the time provided by the camera's built-in time module.
Sync with NTP Server	NTP Server: A server used to sync time with the distributed server and client via NTP protocol. To sync the server time, you need to configure the NTP server address, port, and update interval. NTP Server NTP Server Address 10.1.1.1 Test Port 123 Update Interval(s) 600 • NTP Server Address: Enter the NTP server address and click Test to check the network communication. A message will appear if the NTP is verified successfully. • Port: Range: 1-65535, integer only, default: 123. • Update Interval (s): Range: 30-3600, integer only, default: 600.
Sync with Management Server(Non-ONVIF)	The camera regularly syncs time with the management server that is not connected via Onvif.
Sync with Management Server(ONVIF)	The camera regularly syncs time with the management server connected via Onvif.
Sync with Latest Server Time	Default sync mode. The camera regularly syncs time with all the connected servers.
Sync with Intelligent Server(LAPI)	The camera regularly syncs time with the management server connected via LAPI.

(2) Set the time zone as needed. The default is **(UTC+00:00) London, Dublin, Lisbon**. You can set it as needed.

(3) Click **Sync with Computer Time**.

3. Click **Save**.

7.1.3.2 DST

DST (Daylight Saving Time) is a local time system designed to make full use of daytime to save energy, which sets clocks forward by one hour in summer months.

By default, this function is disabled.

 **Note:** DST rules vary in different countries.

1. Go to **Setup > System > DST**.

DST

DST



Start Time

Mar

Second

Sun

00:00

End Time

Nov

First

Sun

00:00

DST Bias

60mins

Save

2. Enable **DST**.
3. Set the start time, end time, and DST bias as needed.
4. Click **Save**.


7.1.4 OSD

On Screen Display (OSD) refers to characters overlaid on live video or photo, allowing date, time, or other customized contents.

7.1.4.1 Video OSD


1. Go to **Setup > Common > OSD > Video OSD**.

- Layout Mode 1



Overlay Area		Display Style		
Enable	No.	Overlay OSD Content	X-Axis	Y-Axis
☒	1	<Date & Time>	93	0
☐	2	None	75	3
☐	3	None	2	75
☐	4	None	0	0
☐	5	None	0	0
☐	6	None	0	0
☐	7	None	0	0
☐	8	None	0	0

- Layout Mode 2



No.	Area	Overlay OSD Content
1	Area1	<Date & Time>
2	None	
3	None	
4	None	
5	None	
6	None	
7	None	
8	None	


Display Style	
Effect	Background
Font Size	X-large
Font Color	#ff78ff
OSD Inverse	Off
Min. Margin	None
Date Format	dd/MM/yyyy
Time Format	HH:mm:ss

dd=Day; dddd=Day of the week; M=Month; y=Year
h/H=12/24 Hour; tt=A.M. or P.M.; mm=Minute; ss=Second

2. Configure OSD displayed on the live video. Up to 8 OSDs are allowed.
 - (1) (Only applicable to layout mode 1) Select the checkboxes in the **Enable** column to overlay the corresponding OSD contents on live video.

(2) Select OSD content you want to overlay from the **Overlay OSD Content** column.

- Custom: Customizes the OSD contents.
- Date & Time: Displays the current date and time of the camera according to the set format (content style), for example, Thursday, 25 August, 2022 20:04.
- Zoom: Displays the zoom information of the PTZ, for example, Z: 1.00X.
- Time: Displays the current time of the device.
- Date: Displays the current date of the device.
- Total Area Parking Space Availability: Shows the total number of vacant spaces across all configured areas.
- Area 1/2/3/4 Parking Space Availability: Displays the number of vacant spaces individually for the areas.
- License Plate: Displays the pass-thru plate number and its pixel data in real time.



- Device Latitude and Longitude Coordinates: Displays the latitude and longitude coordinates of the device.

(3) Set the exact position of the OSD.

- Layout mode 1: The top left corner of the image is the origin (0, 0), the horizontal axis is the X-axis, and the vertical axis is the Y-axis. Enter the X and Y coordinates to set the horizontal and vertical axis individually.
- Layout mode 2: Click  to enter edit mode.
 - X / Y: The coordinate system origin (0, 0) is at the top-left corner of the video image. X-axis: Positive direction extends horizontally to the right. Y-axis: Positive direction extends vertically downwards. Input specific X and Y values to set the horizontal and vertical position of the overlay area.
 - Alignment: Click the dropdown menu to select left alignment or right alignment. This applies to multiple lines of OSD contents within the same area.

(4) (Applicable to layout mode 2) When multiple OSDs exist within the same display area, use   to adjust their vertical display order.

3. Set the OSD display style.

Effect	Background
Font Size	X-large
Font Color	 #F44336 
OSD Inverse	☐
Min. Margin	None
Date Format	dd/MM/yyyy dd=Day; dddd=Day of the week; M=Month; y=Year
Time Format	HH:mm:ss h/H=12/24 Hour; tt=A.M. or P.M.; mm=Minute; ss=Second

4. Complete the other OSD configurations.

7.1.4.2 Photo OSD

Configure OSD displayed on the photo.

1. Go to **Setup > Common > OSD > Photo OSD**.

2. Configure parameters.

Parameter	Description
Effect	• Background: The OSD information has a background. You need to set the background color. • Normal: The OSD information background is transparent. The background color setting does not take effect even if configured.
Font Size/Character Spacing/ Font Color	Set as needed.
Time Format/Date Format	Set as needed.
Information Displayed on Photo	Time and Plate Number are enabled by default. The following takes Device ID as an example. (1) Select the Device ID checkbox. (2) (Optional) Set the custom name and overlay format. (3) Choose the overlay area. Up to 8 OSDs are allowed, corresponding to Area 1 to Area 8. You can drag the area name on the left live view page to adjust the OSD position. (4) Set Space Count and Line Feed Count. 0 means no line break. (5) You can click to rearrange the order of OSDs if multiple OSDs are overlaid on the same area. (6) To delete an OSD, click or clear the corresponding checkbox.

3. Click **Save**.

7.1.5 External Device

7.1.5.1 Serial Port

Set RS485 serial port and LED screen display parameters.

- RS485 serial port: Enable transparent data transmission and OSD overlay with third-party devices. The serial port parameters must match those of the connected serial device.
- LED Screen Display: This function is available on devices that support LED screen connection.

1. Go to **Setup > Common > External Device > Serial Port**.

RS485_1

Port Mode	Trans-Channel
Baud Rate	9600
Data Bits	8
Stop Bits	1
Parity	None
Flow Control	None

Enable Trans-Cha... ☐

Save

2. Set RS485_1 parameters.

Item	Description
Port Mode	• Trans-Channel: The camera serves as a transmission channel. It does not process the uploaded or downloaded signals, but only transmits them. Enable the transparent channel to use this mode (you also need to set the corresponding serial port baud rate according to the peripheral device protocol). • 485-ONLY-PLATE: Reports license plate numbers using the RS485 protocol. Only one of RS485_1 and RS485_2 can be configured with this mode.
Baud Rate	Data transmission speed (unit: bits per second). The greater the value, the faster the transmission speed, and the shorter the transmission distance. Usually the default value is applicable.
Data Bits	The actual number of data bits in a group of data packets. Usually the default value is applicable.
Stop Bits	Indicates the end of transmission of a group of data. Usually the default value is applicable.
Parity	Used to check whether the received data bits are erroneous. You can choose None , Odd-Parity Check , or Even-Parity Check .
Flow Control	Used to control data transmission to prevent data loss.
Enable Trans-Channel	Optional. The camera establishes transparent data transmission with third-party device via the RS485 serial port. Enter the destination IP address and port number (i.e., the IP address and port number of the third-party device for transparent channel connection).

3. Set RS485_2 parameters by referring to the steps above.

- Set LED parameters.

Item	Description
Port Mode	Default: UV2.0
Keetime(s)	Display duration of recognized license plate information.
Scene	5 scenes are available, including Idle, Allowlist Vehicle Passing, Blocklist Vehicle Passing, Temporary Vehicle, and Unlicensed Vehicle. The LED display will show the preset information when entering the corresponding scene. (1) Select a scene. (2) Select the Enable checkbox; otherwise, the content display will fail in corresponding scene. (3) Configure the display parameters. See the description below for content format. (4) Follow the first three steps to complete display content configuration for all scenes.

- Click **Save**.

7.1.5.2 Wiegand Interface

The Wiegand interface can be used to connect external IC or CPU card readers.

- Go to **Setup > External Device > Wiegand Interface**.

Wiegand Output_1

Protocol:

Format:

Save

- Set Wiegand port parameters.

Parameter	Description
Protocol	Choose Wiegand 26 or Wiegand 34. Default: Wiegand 34. - Wiegand 26: Reads 3-byte card numbers. - Wiegand 34: Reads 4-byte card numbers. None: Disable the Wiegand card reading function.
Format	The card number read by our card readers is in ascending order. Two options are available: - Ascending Order (default): Used when the sequence of card number read by the external card reader is the same as the sequence of card number read by our card readers. - Descending Order: Used when the sequence of card number read by the external card reader is opposite to the sequence of card number read by our card readers.

- Click **Save**.

7.1.6 Vehicle List

7.1.6.1 Vehicle List

Configure the vehicle list and entry policy if there are restrictions on automatic vehicle entry.

Matching

Matching Mode

Allow Unmatched ...

Approximate matching is achieved by setting "Allow Unmatched Character(s)".

 **Note:** If 1/2 is set, it is possible that vehicles with different license plates may be recognized as the same vehicle within a short period of time.

- 0: When the recognized license plate completely matches a plate on the allowlist or blocklist, the plate is considered on the allowlist or blocklist.
- 1/2: When the recognized license plate only has 1/2 character(s) that does not match the license plate on the allowlist or blocklist, the plate is considered on the allowlist or blocklist.

Exact Matching

Matching Mode

Similar Char... ? →

Character Pair	Operation
----------------	-----------

When the recognized license plate completely matches a plate on the allowlist or blocklist, then the plate is considered on the allowlist or blocklist.

Similar Characters: First, match according to the recognized license plate. When the match fails, the specified characters will be replaced with the preset characters for matching again.

 **Note:** Similar characters only take effect in **Exact Matching** mode, not in **Matching** mode.

7.1.7 Vehicle Release Configuration

Specify vehicle release rules for the camera. Different release modes correspond to different configuration parameters.

Go to **Setup > Common > Vehicle Release Configuration**.

By default, the alarm output 1 controls the gate to open and the alarm output 2 controls the gate to close.

Let Through via Camera Control

After a vehicle is captured, the camera determines whether the conditions are met and controls the gate automatically.

Camera-Controlled Co...	Alarm Output 1
Allowlist Vehicle Passing	☒
Blocklist Vehicle Passing	☐
Temporary Vehicle Passing	☐
No Plate	☐
Plate Color 	☐

Camera Control Condition	Description
Allowlist Vehicle Passing	When the captured vehicle belongs to the Allowlisted Vehicle in Vehicle List : - On: Let the vehicle through. - Off: Do not let the vehicle through.
Blocklist Vehicle Passing	When the captured vehicle belongs to the Blocklisted Vehicle in Vehicle List : - On: Let the vehicle through. - Off: Do not let the vehicle through.
Temporary Vehicle Passing	When the captured vehicle belongs to neither the Allowlisted Vehicle nor the Blocklisted Vehicle in Vehicle List , it is a temporary vehicle. In this case: - On: Let the vehicle through. - Off: Do not let the vehicle through.
No Plate	When the captured vehicle cannot be recognized with a license plate, it is a no-plate vehicle. In this case: - On: Let the vehicle through. - Off: Do not let the vehicle through.
Plate Color	First click  to select the license plate color. When the captured license plate color matches one of the selected colors: - On: Let the vehicle through. - Off: Do not let the vehicle through.

Let Through via Camera Control When Offline

Offline: Refers to the state where HTTP&MQTT, HTTP (ZS), zs-http, SDK, and openSDK are all offline.

- When not offline: The platform controls the gate by default.
- When offline: The camera controls the gate automatically. For details, see [Let Through via Camera Control](#).

Online Release Condi...	Alarm Output 1
Platform Release	☒

Camera-Controlled Co...	Alarm Output 1
Allowlist Vehicle Passing	☒
Blocklist Vehicle Passing	☐
Temporary Vehicle Passing	☐
No Plate	☐
Plate Color 	☐

Let Through via Platform Control

All parameters in this mode must be enabled; otherwise, the settings will not take effect.

When a vehicle in the allowlist passes, the camera will control the gate to open; other vehicles are controlled by the platform to open the gate.

Release Condition	Alarm Output 1
Platform Release	☒

Camera-Controlled Co...	Alarm Output 1
Allowlist Vehicle Passing	☒

Let Through Automatically When Offline

Intelligent Platform Select this when "HTTP&MQTT" is selected. This mode is enabled and controlled directly by the platform. It cannot be selected on the web interface and is for display only.

7.1.8 Platform Access

7.1.8.1 Intelligent Platform

After connected to the photo server, the camera will automatically upload real-time access records and captured images when network connectivity is maintained. A camera can be managed by two photo servers.

1. Go to **Setup > Network > Intelligent Platform**.

Intelligent Server 1
Enable ☒
Protocol Video&Image Database
Transfer Protocol HTTP
Server IP 0.0.0.0
Server Port 5073
LPR ID EZIPC0
Device ID 001
Username admin
Password
Confirm Platform
Save

Real-time Status
Intelligent Ser... Offline
Intelligent Ser... Offline
Edge Storage Normal
Internet Conn... Disco...
LED: Off

2. Enable **Intelligent Server 1**.

When enabled, the camera can be connected to the platform 1 via the protocol; when disabled, the camera cannot be connected to the platform 1.

To connect the camera to the platform, add the camera on the platform, and configure the following parameters on the camera.

3. Choose a protocol and configure the parameters.
 - Video&Image Database

Protocol Video&Image Database ▾

Transfer Protocol ... HTTP ▾

Server IP 0.0.0.0

Server Port 5073

LPR ID EZIPC0

Device ID 001

Username admin

Password

Confirm Platform

Coordinate Mode Percentage Mode ▾

Connection Mode Short Connection ▾

Report Data Type ☒ Motor Vehicle ☒ Non-Motor Vehicle ☒ Person ☒ Face

Parameter	Description
Transfer Protocol Type	- HTTP - HTTPS
Server IP/Port	The server IP address and port of the platform.
LPR ID/Device ID	Use the default.
Username/Password/Confirm	Username and password used to log in to the VIID server.
Coordinate Mode	Choose Percentage Mode (default), Pixel Mode , or Normalized Mode .
Connection Mode	Choose Short Connection (default) or Standard .
Report Data Type	Choose Motor Vehicle , Non-Motor Vehicle , Person , or Face .

- FTP

Configure FTP

Server Parameters

Server IP

0.0.0.0

Plate Separator

Custom Naming R...

Port No.

21

Upload Images

Username

Test

Test

Password

Confirm

Save To:\

File Path

File Name

No.

Naming Element

Naming Rule

Cancel

OK

Server Parameters

Parameter	Description
Server IP	Set the FTP server address.
Port No.	Use the default 21. You can set it as needed.
Username	Enter the FTP server username.
Password	Enter the FTP server password.
Test	Click to test the connection to the FTP server.
Upload Images	Select the checkbox to enable uploading non-smart snapshots. Overwrite Storage: After the number of photos in the lowest-level folder reaches the set threshold, new photos will overwrite older photos in the folder. For example, the storage path is "\IP\date", the lowest-level folder is the level-2 folder named "date". When the number of photos uploaded on Jan. 4, 2022 reaches 1000 (default value), new photos overwrite old photos in the 20220104 folder.  Note: To choose Overwrite Storage, make sure the last naming element of the files is the image sequence number.
Custom Naming Rule	Select the checkbox, and then you can set the file naming rules as needed.
Covert Path into UTF8	Select the checkbox, and the path will be converted into UTF8 format.

Save Path

Parameter	Description
File Path	Six levels are allowed. If not set, the default path "\IP\Date\Common" will be used, where "Common""means non-smart snapshots.
File Name	Up to 20 fields are allowed. If not set, sequence numbers will be used as file names, for example, "1, 2, 3", etc.

- HTTP&MQTT

Protocol

Server IP

Server Port

Parking Lot ID

Camera No.

AES Encryption ☐

Quick Report of V... ☐

Keep-Alive Interva...

Image Filling Mode ☐ No Filling ☒ Base64 Encoding ☐ EZCloud to URL ☐ Alibaba OSS

HTTP API Endpoint

Heartbeat Keepali...

Alarm Report Path

Basic Data Path

Passing Vehicle S...

Parameter	Description
Server IP	Set the HTTP server address.
Server Port/ Parking Lot ID/ Camera No.	Use the defaults.
AES Encryption	When enabled, the data security can be protected effectively, preventing unauthorized access and tampering.
Advanced Settings	Storage paths for different data. Use the defaults.
Enable MQTT Server	MQTT server can receive, store, and forward messages. Cameras can publish messages to specific topics for information sharing. Other devices may subscribe to these topics to receive relevant messages. When enabled, please configure the MQTT server address, port, login information, request topic, and response topic.

- If you need to manage the camera via two photo servers, enable Platform 2 and configure the server parameters (only supports VIID and FTP protocols).
- Click **Save**.

7.1.8.2 EZCloud

Add the camera to EZCloud so you can remotely access, monitor, and manage the camera.

You can add the device to EZCloud via the following methods.

 **Note:** After you connect your device to the cloud, we will collect information such as device IP address and serial number to manage the device on the cloud. If you do not agree with our collection of the information, please do not enable this function.

Go to **Setup > Network > EZCloud**, and enable **EZCloud**.

EZCloud  

Address en.ezcloud.uniview.com

Register Code 

Device Status Offline

Scan 

Save

Option 1: Add device on the UniEase app

1. Scan the QR code on the EZCloud page or search UniEase in the app stores to download and install the app.
2. Register an account and log in to the app.
3. Tap + on the home screen.
4. Scan the register code on the camera or on the Quick Guide, and then tap **OK**.
5. Select a connection method according to the actual situation.
6. Follow the on-screen instructions to add the device.

 **Note:** The actual operations may be slightly different, please follow the instructions in the app.

Method 2: Add device on the EZCloud website

1. Visit global.ezcloud.uniview.com using a web browser, and the login page appears.
2. Click **Sign Up** and follow the on-screen instructions to create an account.
3. Log in to the EZCloud.
4. Go to **Device Management**, and click **Add**.
5. Select an add method, complete the information input, and click **OK** to save. For details, see the corresponding manual.

7.1.8.3 WebSocket

WebSocket can connect your camera to a third-party platform and enable remote management of the camera from the third-party platform, including viewing device version and capabilities, control PTZ, and receive alarms.

1. Go to **Setup > Common > Platform Access > WebSocket**.

WebSocket ☐

Destination IP

Destination Port

Device ID

Authentication Key

Confirm Authentic...

Encryption ☐

Online Status Offline

Save

2. Configure the parameters.

Item	Description
WebSocket	Click On/Off to enable/disable WebSocket.
Destination IP	Enter the IP address of the third-party platform.
Destination Port	Enter the listener port of the third-party platform.
Device ID	It is the device's serial number by default. You can set it as required by following the rules prompt on the interface.
Authentication Key	Enter the authentication key used to connect the camera to a third-party platform. Make sure the authentication key configured on the camera and the third-party platform is the same.
Encryption	Encrypt via the SSL protocol. Enable encryption to enhance the security of data transmission.  Note: If you first choose not to enable Encryption and then enable it after the camera is connected to the platform, encryption does not take effect immediately; it will take effect when the next time the camera is successfully connected to the platform.
Confirm Authentication	Confirm the password by entering it again.
Online Status	Check whether the device is successfully connected to the third-party platform.

3. Click **Save**.

7.1.9 Smart

7.1.9.1 Intelligent Configuration

Go to **Setup > Smart > Intelligent Configuration**. After completing the configuration, click **Save**.

Small Photo of Plate

| Small Photo of Plate

☒ Generate Color Photo

When enabled, a closeup image of the license plate will be automatically generated upon a snapshot is captured, and displayed in the top-right corner of the live view page. If the platform subscribes to the messages, the closeup image will also be pushed to the platform.

Country

| License Plate

Detection Region

Common

Choose the country where the license plate is applicable.

Vehicle Characteristics Recognition

When enabled, the vehicle characteristics can be recognized, including vehicle model, brand, logo, and color, and overlaid on the vehicle's composite photo along with OSD.

7.1.9.2 Smart Service


Go to **Setup > Smart > Smart Service**. Click **Save** after configuration.

Currently, two parking space detection modes are supported: license plate recognition and vacant parking space counting.

License Plate Recognition

Draw the parking area in the live view to perform license plate recognition on vehicles within that area. Recognition results are displayed in real-time in Live View and historical records can be viewed in Photos.

 **Note:** Each area can accommodate only one vehicle. A maximum of 4 recognition areas can be added.



Parking Space Configuration

Parking Space Detection... **Plate Recognition**

New Parking Space **Add**

No.	Enable Detection	Area No.	Space No.	
1	☒	A	A1	
2	☒	A	A2	
3	☒	A	A3	
4	☒	A	A4	

Smart Parameters

Cross Parking Space Ala... ☐ On ☒ Off

Save

Live View


Pause

1. Select **Plate Recognition** as the parking space detection mode.
2. Click **Add**. A new parking space entry will be added to the list and enabled automatically. Simultaneously, a new rectangular box will appear in the live view on the right.
3. Drag the four corners of the rectangular box to ensure it covers exactly one complete parking space.
The sequence number at the bottom-left corner of the box corresponds to the No. column in the list.
4. Customize the area ID and parking space ID.
5. Configure Cross Parking Space Alarm. When enabled, the device will generate an alarm if it detects a vehicle parked across multiple spaces.


Vacant Parking Space Counting

Identifies vehicles within the detection area to calculate the number of occupied and vacant parking spaces.


 **Note:** Prerequisite: At least one target calibration must be completed in [Target Calibration](#). Without this reference baseline, the feature cannot guarantee vehicle detection accuracy.



1. Select **Vacant Parking Space Count** as the parking space detection mode.
2. Select a counting mode and configure the rules:
 - Area: Supports counting for up to 4 areas simultaneously. The total number of parking spaces across all 4 areas must not exceed 50.



- (1) Click **Add**. A new area entry is added to the list and enabled automatically. A green rectangular box appears in the live view on the right.
 - (2) Drag the four corners of the box to cover multiple complete parking spaces.
The ID at the bottom-left corner corresponds to the No. column in the list.
 - (3) Customize the area ID.
 - (4) Enter the total number of spaces for this area.
 - (5) Select the vehicle type. Once saved, this area will only recognize the selected vehicle type. Vehicle types must be calibrated and added in [Target Calibration](#) beforehand)
- Parking Space: Supports counting vacant parking spaces from up to 50 parking spaces simultaneously.



- (1) Set **New Parking Space**. This defines how many spaces to add in one batch. Max 10 spaces can be added at a time.
 - (2) Click **Add**. Corresponding entries are added to the list and enabled automatically. Matching green rectangular boxes appear in the live view.
 - (3) Drag the four corners of each box to cover exactly one complete parking space.
The ID at the bottom-left corner corresponds to the No. column in the list.
 - (4) Customize the area ID and parking space ID.
 - (5) Select the vehicle type. Once saved, this specific space will only recognize the selected vehicle type. Vehicle types must be calibrated and added in [Target Calibration](#) beforehand.
3. Configure illegal parking detection parameters.
 - (1) Enable **Illegal Parking Detection**. A red rectangular box will appear in the live view on the right.
 - (2) Select the number of illegal parking areas. The system supports a maximum of two simultaneous areas. If you select 2, two red rectangular boxes will be displayed.
 - (3) Select a rectangular box and drag its four corners to cover the specific area where illegal parking needs to be detected.
 - (4) Set the violation duration threshold. If a vehicle remains within the red box for longer than this set time, it is classified as an illegal parking violation, and an alarm is triggered. The alarm is automatically cleared once the vehicle leaves the detection area.
 4. Configure congestion detection parameters.
 - (1) Enable **Congestion Detection**. An orange rectangular box will appear in the live view on the right.
 - (2) Set the congestion vehicle threshold. If the number of vehicles detected within the orange box exceeds the set value, the situation is classified as congestion, and an alarm is triggered. The alarm is automatically cleared once the vehicles leave the detection area.

7.1.9.3 Target Calibration

To ensure the camera accurately recognizes various vehicle types, manual target calibration must be performed after installation. The camera uses these calibration results as a baseline for vehicle type identification.

 **Note:** At least one target calibration must be completed before the [Vacant Parking Space Counting](#) feature can be used.

1. Go to **Setup > Smart > Target Calibration**.

The interface shows a 'Start' button and a 'Clear Calibration' button at the top left. Below them is a table for adding targets:

No.	Target Type	Custom Attributes
1	Small Vehicle	bb
2	Bus	

Below this table is a 'Calibration Records' section with a table:

No.	Calibration Time	Calibration Info
1	2026-01-23 17:02:47	View Image
2	2026-01-23 17:07:04	View Image

On the right, a live camera view shows a parking lot. Two cars are highlighted with colored bounding boxes: a purple box around a dark car and an orange box around a light car. A 'Pause' button is located at the bottom left of the live view.

2. Click **Start** to display the following contents.

Target Type Small Vehicle Add

 **Note:** You can calibrate a maximum of 5 targets per type, with a total limit of 15 targets across all types.

3. Select the target type to calibrate and click **Add**. A new rectangular box will appear in the live view on the right.

The ID at the top-left corner of the box corresponds to the No. column in the list.

4. Drag and resize the rectangular box so that it precisely encloses the target object.
5. (Optional) Set custom attributes. If the same target type is calibrated multiple times, you can assign custom attributes to distinguish between different markers.
6. Click **Finish Calibration**. The device will begin extracting features from the targets. This process may take some time. Please wait patiently.

Upon successful calibration, the results will be recorded in the **Calibration Records** list. Click **View Image** to display the selected target.

7.2 System

7.2.1 Time

See **Setup** > **Common** > [Time](#).

7.2.2 User

User Type

- Admin: Has the maximum permissions. Only 1 admin user is allowed.
- Operator: Has all permissions for managing the device and common users.
- Common User: Only has live view and playback permissions. Up to 32 common users are allowed.

Go to **Setup** > **System** > **User**.

Add			
No.	Username	User Type	Operation
1	admin	Admin	

Add

1. Log in to the camera's web interface using the admin account.
2. Go to **Setup** > **System** > **User**.
3. Click **Add**.

Add
×

Username

User Type

Common User ▼

Password

Weak

Medium

Strong

Confirm

Select Permission

☐ Select All

☒ Live View

☐ Playback

Cancel

OK

4. Configure the parameters.

Parameter	Description
Username	Enter the username. 1 to 32 characters are allowed, including uppercase and lowercase letters, digits, underscores, hyphens, dots, and plus signs.
User Type	Choose Operator or Common User .
Password	The more complex the password, the more secure the system. The password shall be 9 to 32 characters consisting at least three of the following elements: digits, lowercase letters, uppercase letters, underscores, and hyphens.
Confirm	Enter the password again.
Select Permission	Select permissions you want to assign to the user.

5. Click **OK**.

Edit User

Change the password (admin password is required) or permissions.

- Log in to the camera's web interface using the admin account.
- Go to **Setup > System > User**.
- Click the user you want to edit, and click **Edit**.
 - Change Admin Info

Edit

×

Username

admin

User Type

Admin

Old Pass...

Password

Weak

Medium

Strong

Confirm

☒ Email

Cancel

OK

- Change Common User/Operator Info

Edit

×

Username

aa

User Type

Common User

Admin P...

Password

Weak

Medium

Strong

Confirm

Select Permission

☐ Select All

Cancel

OK

4. Enter the old password (for admin) or the admin password (for common users).
5. Enter the new password, and confirm the new password.
6. (Optional) Change the email reserved.

Note:

- Only admin can change the reserved email, which is used to receive the security code so as to retrieve the password.
- To change the email reserved, you must also reset the admin password; otherwise, the email update will not be applied.

7. Click **OK**.

Delete

Note: The admin user cannot be deleted.

1. Log in to the camera's web interface using the admin account.
2. Go to **Setup > System > User**.
3. Click the user you want to delete, click **Delete**, and then click **OK** to confirm.

7.2.3 Log

Search operation logs that configure alarm and network parameters.

Go to **Setup > System > Log**.

Export							Total 20 items	Search
No.	Type	Sub Type	Date	Time	Username	IP	Result	
1	Operator	Login	2026-07-15	17:03:48	admin		Succeeded.	
2	Image Setting	Configure Privacy Mask	2026-07-15	16:25:32	admin		Succeeded.	
3	Video & Audio	Configure ROI	2026-07-15	16:25:25	admin		Succeeded.	
4	Video & Audio	Configure ROI	2026-07-15	16:25:25	admin		Succeeded.	
5	Operator	Login	2026-07-15	16:22:30	admin		Succeeded.	
6	Operator	Login	2026-07-15	16:06:15	admin		Succeeded.	
7	Image Setting	Image Setting	2026-07-15	15:36:23	admin		Succeeded.	
8	PTZ	PTZ Control	2026-07-15	15:33:18	admin		Succeeded.	
9	PTZ	PTZ Control	2026-07-15	15:33:18	admin		Succeeded.	
10	PTZ	PTZ Control	2026-07-15	15:33:18	admin		Succeeded.	
11	PTZ	PTZ Control	2026-07-15	15:33:16	admin		Succeeded.	
12	Operator	Login	2026-07-15	15:33:08	admin		Succeeded.	
13	Network	Network	2026-07-15	15:32:22	admin		Succeeded.	
14	Network	Network	2026-07-15	15:32:21	admin		Succeeded.	

Search

1. Set the time range, main type, and sub type.
2. Click **Search**, and the desired logs will be displayed in the list below.

Export

Click **Export** to save search results as a file named **operation .csv**.

7.2.4 Device Info

Set device information including device name, device ID, location, etc. which can be used in smart FTP, OSD, etc.

Note: The functions supported may vary with device model.

1. Go to **Setup > System > Device Info**.

Device Name	1						
Device ID	1						
Intersection Info	road						
Intersection ID							
Longitude	East	0	Degrees	0	Minutes	0.0000	Seconds
Latitude	North	0	Degrees	0	Minutes	0.0000	Seconds

2. Set the device information as needed.
3. Click **Save**.

7.3 Network

7.3.1 Basic Config

7.3.1.1 Network

See **Setup > Common > Network**.

7.3.1.2 DNS

DNS (Domain Name System) is a globally distributed service that translates human readable domain names into numeric IP addresses, facilitating devices to access external servers or hosts through domain names.

Enter the preferred and alternate DNS server addresses. The camera will use the preferred IP address as the DNS server address. If the preferred DNS server is unavailable, the alternate DNS server will be activated.

Go to **Setup > Network > Basic Config > DNS**.

Preferred DNS Se...	8.8.8.8
Alternate DNS Ser...	8.8.4.4

7.3.1.3 DDNS

DDNS (Dynamic Domain Name System) automatically updates the DNS server with the device's dynamic IP address to enable remote Internet access to the device on the network. With DDNS, users can access the private network device for remote control with the public IP address.

1. Go to **Setup > Network > Basic Config > DDNS**.
2. Enable **DDNS Service**.

DDNS Service

DDNS Service ☐

DDNS Type

Server Address

Domain Name

Username

Password

Confirm

3. Select the DDNS type.

- DynDNS/NO-IP: Third-party DDNS service provider, enter the domain name registered with the DDNS provider.
- EZDDNS: Uniview's DDNS service, enter a domain name for your camera.

 **Note:** If your server is located domestically, it is recommended to select a domestic DDNS service provider, as overseas DDNS servers may be blocked by the national firewall.

4. Click **Save**.

7.3.1.4 UNP

If the network environment has a data diode or firewall, you can connect the camera to the network via a UNP(Universal Network Passport).

1. Go to **Setup > Network > Basic Config > UNP**.

UNP Service ☐

Port Type

UNP Mode

UNP Server IP

Server Port

Authentication ☒

Username

Password

Confirm

2. Enable **UNP Service**.

3. Select the port type as needed.

4. Enter the UNP server address.

5. If the UNP server requires authentication, enable **Authentication** and enter the UNP username and password, and confirm the password.
6. Click **Save**.

7.3.1.5 Port

Set HTTP, HTTPS, and RTSP ports. Set the ports as needed when you visit the camera via the network.

1. Go to **Setup > Network > Basic Config > Port**.

HTTP Port	80
HTTPS Port	443
RTSP Port	554

Note: Modifying the RTSP port number will cause the device to restart.

Save

2. You can use the defaults or change them in case of port conflicts.

 **Note:** If the HTTP port number you entered has been used, a message "Port conflicts. Please try again." will appear. 23, 81, 82, 85, 3260, and 49152 have been assigned for other purposes and cannot be used. In addition to the above port numbers, the system can also dynamically detect other port numbers that are already in use.

- HTTP/HTTPS Port: If you change the HTTP/HTTPS port number, then you need to add the new port number after the IP address when logging in. For example, if the HTTP port number is set to 88, you need to use `http://192.168.1.13:88` to log in to the device.
- RTSP Port: Real-Time Streaming Protocol port, enter an available port number.

3. Click **Save**.

7.3.1.6 Port Mapping

1. Go to **Setup > Network > Basic Config > Port Mapping**.

Port Mapping ☒

Mapping Type

UPnP Mapping

Port Type	External Port	External IP Address	Status
HTTP Port	80	0.0.0.0	Inactive
RTSP Port	554	0.0.0.0	Inactive
HTTPS Port	443	0.0.0.0	Inactive

Save

2. Enable **Port Mapping**.
3. Set the mapping type.
 - Auto: The external port numbers and external IP address are assigned automatically.
 - Manual: The external port numbers need to be set manually.
4. Click **Save**.

7.3.2 Service Config

7.3.2.1 E-mail

Configure E-mail so the device can e-mail alarm messages to specified email addresses.

1. Go to **Setup > Network > Service Config > E-mail**.

Sender

Name

Address

SMTP Server

SMTP Port

TLS/SSL ☐

Snapshot Interval(s) ☒ Attach Image

Server Authentication ☒

Username

Password

Confirm

Recipient

Name1

Address1

2. Set the sender and recipient information.

Item		Description
Sender	Sender Name	Enter the device name.
	Sender Address	Enter the device IP.
	SMTP Server/SMTP Port	Enter the IP address and port number of SMTP server of the sender's e-mail. The default SMTP port number is 25.
	TLS/SSL	Enable TLS/SSL to secure e-mail communication.
	Snapshot Interval(s)	Set the interval for taking snapshots to be attached to alarm e-mails.  Note: The interval for taking snapshots attached to alarm e-mails is subject to the settings on the E-mail page.
	Attach Image	When enabled, the device will automatically send an alarm e-mail with 3 attached snapshots taken at set intervals in the event of an alarm.
	Server Authentication	Enable SMTP server authentication to secure e-mail transmission.
	Username/Password	Enter the username and password of the SMTP server.  Note: The email only shows the sender name not the username.
Recipient	Recipient Name/ Address	(1) Enter the e-mail name and address to receive e-mails. (2) After recipient configuration, you can click Test to test the email sending function.

3. Click **Save**.

7.3.2.2 SNMP

SNMP is required for the camera to share configuration information to servers.

1. Go to **Setup > Network > Service Config > SNMP**.
2. Enable **SNMP**.



Note: If SNMP is enabled by default, this occurs due to backward compatibility requirements after upgrading the camera to the latest firmware version. This behavior is expected and normal.

3. Set SNMP parameters.

- SNMPv3



Note: Before you enable SNMPv3, make sure that it is supported both on your camera and the server.

SNMP Type	SNMPv3
Username	admin
Authentication Mode	MD5
Password	
Confirm	
Encryption Mode	DES
Password	
Confirm	
Trap Community ...	private
Trap Server Address	0.0.0.0
Trap Port	162
SNMP Port	161

Item	Description
SNMP Type	SNMPv3 by default.
Password	Set a password for authentication.
Confirm	Confirm the password by entering it again.
Password	Set a password for data encryption.
Confirm	Confirm the password by entering it again.
Trap Server Address	It is automatically filled after the management platform configuration is completed .
SNMP Port	The default is 161. You may change is as needed.

- SNMPv2

SNMP

SNMP ☒

SNMP Type

Read Community

Read/Write Comm...

Trap Community ...

Trap Server Address

Trap Port

SNMP Port

Item	Description
SNMP Type	Select SNMPv2 . After you select SNMPv2, a message pops up to remind you of potential risks and ask if you want to continue. Click OK .
Read Community	The default read community name is public, and you may change it as needed. Make sure the read community names of the server and camera are the same, otherwise the two-way authentication will fail.
SNMP Port	The default is 161. You may change is as needed.

- Click **Save**.

7.3.2.3 ONVIF

If the network connection between the device and the peer (stream receiving address) is disconnected, the device can store videos according to the configured recording schedule; and after the network connection is restored, the device can retransfer the video stored during the interruption period to the stream receiving address on the request of the peer.

Go to **Setup > Network > Service Config > ONVIF**.

ANR (ONVIF) ☐

Stream Address

Save

7.3.2.4 802.1x

802.1x is a client/server-based access control and authentication protocol. When the device functions as an 802.1x client, only imported certificates and CA certificates can pass server authentication. The network connection will fail if the self-signed certificate and the default certificate are unable to pass authentication.

- Go to **Setup > Network > Service Config > 802.1x**.

802.1x ☐

Protocol

EAPOL Version

Username

Password

Confirm

2. Enable **802.1x**.
3. Select a protocol. The camera can establish network communication only after successful protocol authentication.

- EAP-MD5

Protocol

EAPOL Version

Username

Password

Confirm

(1) Choose the EAPOL version according to the protocol version on the network switch.

(2) Enter the device username and password, and confirm the password.

- EAP-TLS

Protocol

EAPOL Version

Username

Client Certificate

CA Certificate

(1) Choose the EAPOL version according to the protocol version on the network switch.

(2) Enter the username.

(3) Click ▼ to select the client certificate and CA certificate. See [Certificate Management](#) for detailed certificate settings.

4. Click **Save**.

7.3.3 Platform Access

See **Setup > Common > Platform Access**.

7.3.4 Dual-Camera Parameters

To use primary and secondary camera mode and single-channel camera for mix entry&exit mode, you should complete the relevant configurations on the cameras for inter-camera communication.

Note:

- The two modes cannot be enabled simultaneously on the camera.
- The two camera versions must be consistent when using the two modes.
- When an LED display is required, both cameras must use the same display style, with each LED screen configured as a 4-row × 4-character matrix.

1. Go to **Setup > Network > Dual-Camera Parameters**.

Dual-Camera Mode ☒ Off ☐ Single-Channel Camera for Mix Entry&Exit ☐ Primary and Secondary Cameras on Same Side

Save

2. Choose a dual-camera mode and configure the parameters.

- Off: This function is disabled.
- Single-Channel Camera for Mix Entry&Exit: Applicable to mixed entry and exit scenarios. Both cameras must select this mode.

Secondary Camera IP: The IP address of the other camera.

Dual-Camera Mode ☐ Off ☒ Single-Channel Camera for Mix Entry&Exit ☐ Primary and Secondary Cameras on Same Side

Secondary Camer...

Match Time for En...

Save

- Primary and Secondary Camera on Same Side: When a single camera cannot capture all passing vehicles at one exit/entrance, you can install two cameras with the same mode and enable **Primary and Secondary Camera on Same Side** to capture all passing vehicles.

Dual-Camera Mode ☐ Off ☐ Single-Channel Camera for Mix Entry&Exit ☒ Primary and Secondary Cameras on Same Side

Camera Type ☐ Primary Camera ☐ Secondary Camera

Secondary Camer...

Dual Camera Sna...

Save

- Function Introduction: For example, there are two cameras. Camera A is the primary camera, with a recognition result of a, while Camera B is the secondary camera, with a recognition result of b. Camera B transmits its recognition results to Camera A. Camera A then compares both results (A and B) and uploads the optimal results to the server. If the time difference exceeds the specified threshold during capture, the system directly reports the first record.
- Extended Function-LED Display: After the primary camera and secondary camera have been configured, connect the LED displays to the cameras respectively. The primary camera will then sync the received LED display information with the secondary camera to output synced content.
- Configuration Description:

- (1) Enter the **Dual-Camera Parameters** page of the camera A, set **Dual-Camera Mode** to **Primary and Secondary Camera on Same Side**, set **Camera Type** to **Primary Camera**, enter the IP address of the secondary camera B, and click **Save**.
- (2) Enter the **Dual-Camera Parameters** page of the camera B, set **Dual-Camera Mode** to **Primary and Secondary Camera on Same Side**, set **Camera Type** to **Secondary Camera**, enter the IP address of the secondary camera A, and click **Save**.

 Note:

- When the primary and secondary cameras are connected to LED displays, the display type and protocol must be the same.
- When **Primary and Secondary Camera on Same Side** is enabled, **Quick Report of Vehicle Passing Through** for HTTP protocol in the server photo is unavailable and will be forcibly disabled during data upload.
- Once the primary camera is configured, all settings will automatically sync to the secondary camera without requiring manual setup.
- After primary and secondary cameras configuration are complete, the secondary camera time will automatically sync with the primary camera time.
- When the two cameras run different versions, it is recommended to upgrade both to the latest version before primary camera and secondary camera configuration.
- When the two cameras are different models, contact the technical support for primary camera and secondary camera configuration.

3. Click **Save**.


7.4 Security

7.4.1 Network Security

7.4.1.1 HTTPS

HTTPS is a secure version of the HTTP protocol that uses SSL protocol to authenticate both a client and a server, and encrypt data during transmission to prevent data from being stolen or altered, enhancing data security.

1. Go to **Setup > Security > Network Security > HTTPS**.



2. Enable **HTTPS**.
3. Click **Save**.

7.4.1.2 Authentication

Configure RTSP authentication and WEB authentication to improve the security of network transmission. Only after successful authentication can data such as videos, audios, texts, and images be transferred on the network.

1. Go to **Setup > Security > Network Security > Authentication**.

RTSP Authentication Digest

RTSP Digest Algo... MD5

WEB Authentication Digest

WEB Digest Algori... MD5

Save

2. Choose an authentication mode.

Parameter	Description
RTSP	- None: Transmits data without authentication. - Basic: Authentication information is transferred in plaintext without encryption, which imposes serious security risks. - Digest: Authentication information is encrypted to provide higher security. - Digest MD5: Digest authentication, which uses MD5 to protect the username, password, and domain of the requester, not transferred on network in plaintext and provides higher security. - Digest SHA256: Digest authentication, which uses SHA256 for authentication and provides higher security than Digest MD5. - Digest MD5/ SHA256: Supports MD5 or SHA256 algorithm adaption.
WEB	- None: Transmits data without authentication. - Digest: Authentication information is encrypted to provide higher security. - Digest MD5: Digest authentication, which uses MD5 to protect the username, password, and domain of the requester, not transferred on network in plaintext and provides higher security. - Digest SHA256: Digest authentication, which uses SHA256 for authentication and provides higher security than Digest MD5. - Digest MD5/ SHA256: Supports MD5 or SHA256 algorithm adaption.

3. Click **Save**.

7.4.1.3 ARP Protection

ARP attack mainly exists in local area network, which forges IP address and physical address (MAC address) to achieve ARP spoofing, causing communication failures among devices within the local area network.

Configure ARP protection, and the device will verify the physical address (MAC address) of the access source, so as to avoid ARP spoofing attacks.

1. Go to **Setup > Security > Network Security > ARP Protection**.

ARP

ARP Protection ☐

Gateway

Gateway MAC Ad... 0

Save

2. Enable **ARP Protection**.
3. Enter the gateway's physical address (legal MAC address).
4. Click **Save**.

7.4.1.4 IP Address Filtering

Use IP address filtering to allow or forbid access from specified IP addresses.

1. Go to **Setup > Security > Network Security > IP Address Filtering**.

IP Address Filtering

IP Address Filtering ☐

Filtering Mode ☒ Allowlist ☐ Deny Access

No.	IP Address	+
-----	------------	---

Save

2. Enable **IP Address Filtering**.
3. Set the filtering mode to **Allowlist** or **Deny Access**. If **Allowlist** is selected, only the added IP addresses are allowed to access the device. If **Deny Access** is selected, only the added IP addresses cannot access the device.
4. Click **+**, and enter IP address(es).
 - Up to 32 IP addresses can be added. Duplicate addresses are not allowed.
 - The first byte of the IP must be 1-233, and the fourth byte cannot be 0. Invalid IP addresses such as 0.0.0.0, 127.0.0.1, 255.255.255.255, and 224.0.0.1 are not allowed.
5. Click **Save**.

7.4.2 Video Security

Use the watermark function to encrypt custom information into video contents to prevent video tampering.

You can view the watermark effect of the video player on the EZPlayer website.

1. Go to **Setup > Security > Video Security**.

Watermark ☐

Watermark Content

Save

2. Enable **Watermark**.

- Set the watermark content, with 0 to 16 characters, including lowercase and uppercase letters, and digits.
- Click **Save**.

7.4.3 Access Policy

Access policies are used to prevent unauthorized access and operation from the network.

- Go to **Setup > Security > Access Policy**.

MAC Authentication ☒

Illegal Login Lock

Illegal Login Lock ☒

Illegal Login Limit

Lock Time (min)

Session Timeout

Session Timeout ☐

Timeout (min)

WEB Service

WEB Service ☒

Save

- Configure the parameters.

- MAC address refers to the hardware address written into the hardware during manufacturing. It can be used to identify the device's location during data transmission at the lower layers of the network.

Enable **MAC Authentication**.

- Illegal Login Lock

 **Note:** When enabled, if the maximum number of illegal access attempts reaches, the camera is locked and unavailable. When disabled, the number of illegal access attempts is unlimited.

Item	Description
Illegal Login Lock	If the client IP address is not on the blocklist, the input username is correct, but the input password is wrong, it is an illegal access attempt.  Note: - The user can unlock the account by disconnecting power and rebooting the camera. - When an account is locked, information including the username, IP address, etc., is logged by the system.
Illegal Access Limit	- Set the maximum number of illegal access attempts allowed. - When the same user accesses the camera using different client IP address, the illegal access limit is determined by the most recent configuration.
Lock Time (min)	Integer within the range of 1-120.

Example: User A tries to log in from the client IP address 192.168.1.33 and is locked. Then user A cannot log in within the lock time, but user B is not affected and can still log in from the same IP address.

- **Session Timeout:** A session is the connection established between the client (Web browser) and the server (camera). When enabled, the device will log out if there is no user activity (such as clicking or syncing configuration) within the specified time. You will need to log in again from the login page once logged out.

 **Note:** Only admin can enable or disable this feature.

Item	Description
Session Timeout	Click On/Off to enable/disable Session Timeout. Sessions are counted as follows. Take one device as an example. • If the session is established using one web browser from one client IP, there is one session. • If sessions are established using one web browser from one client IP, there are two sessions. • If sessions are established using two web browsers from two client IPs (two browsers from each IP), there are four sessions.  Note: Up to 36 sessions are allowed at the same time.
Timeout (min)	Enter an integer within the range of 1 to 120.  Note: The timer restarts when the session is re-established after a reboot.

 **Note:**

- The friendly password function is available on certain models.
- When **Friendly Password** is enabled, the camera's web interface can be used normally. When **Friendly Password** is disabled and a user logs in to the camera's web interface with a weak password, the password change page will appear and forcibly ask the user to change the password into a strong one.

3. Click **Save**.

7.4.4 Certificate Management

A certificate is an electronic file that uniquely represents individuals and resources on the Internet and enables secure and confidential communications between the two entities. On the **Certificate Management** page, you can set different servers, create CA certificates, view certificate properties, etc.

Go to **Setup > Security > Certificate Management**.

Certificate		CA Certificate			
Create Self...		Import Certi...			
Certificate Name	Valid From	Valid To	Certificate Status	Function	Operation
default	2026-06-29 12:46:24	2027-06-29 12:46:24	Normal	HTTPS	   

7.4.4.1 Certificate

Create Certificate

Create a self-signed certificate or import a certificate.

- Create a self-signed certificate for application scenarios with low-security requirements. It is a digital certificate issued by an untrusted CA (Certificate Authority), such as a company or software developer.

Create Self-Signed Certificate

×

Certificate Name

Public Key

2048

Country

Example: CN

Domain Name/IP

Valid Period(day)

Province

City

Organization

Cancel

OK

1. Click **Create Self-Signed Certificate**.

2. Configure the parameters.

Item	Description
Certificate Name	Set as needed.
Public Key	Choose a length for the public key: 2048 or 1024. Default: 2048.
Country	Enter the two-character country code, for example, CN for China.
Domain Name/IP	Enter the device's IP address or domain name.
Valid Period(day)	Enter the validity period of the certificate.
Province	Enter the complete province name.
City	Enter the complete city name.
Organization	Enter the organization name.
Organizational Unit	Enter the organizational unit name.
Email	Enter a valid email address.

3. Click **OK**.

- Import a non-CA certificate.

Import Certificate

×

Import Format

Certificate+Private Key

Certificate Name

Certificate

Browse

Private Key

Browse

Private Key Pass...

Cancel

OK

1. Click **Import Certificate**.

2. Configure the parameters.

Item	Description
Import Format	You may choose Certificate+Private Key , PKCS#12 , or Self-Signed Request Certificate .
Certificate Name	Enter the certificate name.
Certificate	Click Browse and locate the certificate.
Private Key	Click Browse and locate the private key.
Private Key Password	Enter the private key password.

3. Click **OK**.

- (Optional) Create a certificate request to obtain a trusted signed certificate for application scenarios with high-security requirements.

1. After creating or importing a certificate, select the certificate, and click **Create Certificate Request**.
2. Configure the parameters.
3. Click **OK**.



Note: After the certificate request is created, export the certificate request file. After the certificate authority (CA) signs and issues a certificate in accordance with the request, import the certificate into the device.

Export Certificate

Click **Export Certificate** to save the certificate to your computer.

Delete Certificate

Select a certificate and delete it. A certificate that is in use cannot be deleted.

Certificate Properties

Select the certificate to view its properties.

7.4.4.2 CA Certificate

CA is an authority that issues certificates. It can sign and issue certificates, and manage certificates issued. A CA certificate is a self-signed certificate issued by an untrusted certificate authority (CA) and thus is more secure and reliable.

1. Click **Import Certificate**.
2. Enter the certificate name, and select the certificate.

Import Certificate

Certificate Name

Certificate

3. Click **OK**.

- Delete Certificate

Select a certificate and delete it. A certificate that is in use cannot be deleted.


- Certificate Properties

Select the certificate to view its properties.

7.4.5 Registration Info

The manufacturer information is provided on the management platform.

1. Go to **Setup > Security > Registration Info**.



2. Enable or disable **Hide Vendor Info** as needed.
3. Click **Save**.

7.5 Image

7.5.1 Image

7.5.1.1 Image

You need to complete scene configuration first, and then configure image parameters. The image settings are saved automatically.


1. Go to **Setup > Image > Image > Image**.
2. Configure scene parameters. Each scene corresponds to each image parameters. Up to 5 scenes are allowed to meet various scene requirements.

No.	Current	Image Scene Template	Image Scene Name
1	☒	<Road Highlight Compensation(... ▾	Scene1
2	☐	<Road Highlight Compensation(... ▾	Scene2
3	☐	<Road Highlight Compensation(... ▾	Scene3
4	☐	<Road Highlight Compensation(... ▾	Scene4
5	☐	<Road Highlight Compensation(... ▾	Scene5

- (1) ☒ means the scene is currently in use. To switch scenes when **Enable Auto Switch** is disabled, click ☐ before the scene name, and the image settings will also switch to the corresponding image settings configured for the scene.
- (2) Set the scene name. The device provides several predefined scene modes for different scenarios. After a scene mode is selected, image parameters are automatically switched, you can also adjust the parameters as needed.
 - Common: Recommended for outdoor scenes.
 - Road Highlight Compensation: Apply brightness compensation to the road scene to enhance the image, thereby improving the recognition accuracy that may be compromised by overly dark images.
 - Test: For testing.
 - Custom: Set a scene as needed.
3. Go to the **Image Enhancement** tab to configure the parameters. You can click **Default** on the left to restore the default factory settings.

Brightness	<input type="range"/>	128
Saturation	<input type="range"/>	128
Contrast	<input type="range"/>	128
Sharpness	<input type="range"/>	128
2D Noise Reduction	<input type="range"/>	128
3D Noise Reduction	<input type="range"/>	128

Parameter	Description	
Brightness	The overall lightness or darkness of the image.   Low brightness High brightness	
Saturation	The intensity or vividness of colors in the image.   Low saturation High saturation	
Contrast	The black-to-white ratio in the image, that is, the gradient of color from black to white.	

Parameter	Description	
	 Low contrast	 High contrast
Sharpness	The definition of edges in the image.   Low sharpness High sharpness	
2D Noise Reduction	Reduce noise by individually analyzing each frame, which may cause image blur.	
3D Noise Reduction	Reduce noise by analyzing the difference between successive frames, which may cause image smearing or ghosting.	

- Go to the **Exposure** tab to configure the parameters. You can click **Default** on the left to restore default factory settings.

Exposure Mode Custom

Shutter(s) 1/100000 ~ 1/500

Gain 0 ~ 40

Iris F9.6 ~ F1.6

Slow Shutter ☐

Slowest Shutter 1/25

Compensation 0

Day/Night Mode Automatic

Day/Night Sensitivity Medium

Day/Night Switchi... 3

HLC Intensity 5

Parameter	Description
Exposure Mode	- Automatic: The device automatically adjusts the exposure parameters based on the environment. - Custom: User can set exposure parameters as needed.
Shutter(s)	Shutter is used to control the light that comes into the lens. A fast shutter speed is ideal for scenes in quick motion. A slow shutter speed is ideal for scenes that change slowly. The default range is 1/100000 to 1/25. Note: - This parameter is configurable when Exposure Mode is set to Custom. - If Slow Shutter is disabled, the reciprocal of the shutter speed must be greater than the frame rate.
Gain	Control image signals so that the device can output standard video signals in different light conditions. Note: This parameter is configurable when Exposure Mode is set to Custom.
Slow Shutter	When enabled, the device can improve image brightness in low light conditions.
Slowest Shutter	Set the slowest shutter speed for exposure.

Parameter	Description
Compensation	Adjust the compensation value as required to achieve the desired image effect.
Metering Control	Set how the device measures the intensity of light. The default is Center-Weighted Average Metering. You can choose the mode as needed. - Center-Weighted Average Metering: Measure light mainly in the central part of the image. - Evaluative Metering: Measure light in the specified area of the image, suitable for scenes where the target and the background contrast widely. - Vehicle Metering: Applicable to vehicle driving scenarios.  Note: This parameter is configurable when Exposure Mode is not set to Manual.
Day/night mode	- Automatic: The device automatically switches between day mode and night mode according to the ambient lighting condition to output optimum images. - Day: The device outputs high-quality images in daylight conditions. - Night: The device outputs high-quality images in low-light conditions.
Day/Night Sensitivity	Light threshold for switching between day mode and night mode. A higher sensitivity value means that the device is more sensitive to the change of light and is therefore more easily to switch between day mode and night mode.  Note: This parameter is configurable when Day/Night Mode is set to Automatic.
Day/Night Switching(s)	Set the length of time before the camera switches between day mode and night mode after the switching conditions are met.  Note: This parameter is configurable when Day/Night Mode is set to Automatic.
WDR	- On: The bright and dark areas on the image can be distinguished simultaneously. You need to set the WDR level manually. - Off: The camera displays the original image.  Note: - Typical WDR scenes include: backlighting scenes with significant contrast (such as halls with insufficient lighting); counter-lighting scenes (such as toll booths); scenes with intense light sources. etc. - This parameter is configurable when Exposure Mode is set to Automatic.
WDR Level	When WDR is enabled, you can adjust the WDR level to improve image quality.
Suppress WDR Stripes	Suppress the stripes in the image caused by the flickering light in WDR mode. When enabled, the camera automatically adjusts the shutter and frequency to minimize stripes.

- Go to the **Smart Illumination** tab to configure the parameters. You can click **Default** on the left to restore the default factory settings.

Smart Illumination 

Illumination Mode Infrared

Control Mode Global Mode

Near-illumination ... 100

Far-illumination Le... 0

Parameter	Description
Illumination Mode	Use the default.
Control Mode	• Infrared • Global Mode: The camera automatically adjusts illumination, and the illumination level cannot be adjusted. • Overexposure Restrain: The illuminator is controlled by the day/night mode. The camera automatically adjusts illumination, and the illumination level cannot be adjusted. • Custom Level: Default. The illuminator is controlled by the day/night mode. • White Light • Custom Level: The illuminator is controlled by the day/night mode. The illumination level can be adjusted manually. • Custom Level(Always On): The illuminator is not controlled by the day/night mode, but by the high/low beam settings of the headlights.
Illumination Level	The greater the value, the higher the intensity. 0 is off.

6. Go to the **Focus** tab to configure the parameters. You can click **Default** on the left to restore the default factory settings.

Zoom Limit: Limits the maximum magnification of digital zoom, preventing users from unlimited zooming that causes severe blurring, increased noise, and loss of detail, to balance image clarity and usability.

Max. Zoom Ratio 4

7. Go to the **White Balance** tab to configure the parameters. You can click **Default** on the left to restore the default factory settings.

White Balance is used to adjust red gain and blue gain of the entire image under different color temperatures so as to output images that best suit human eyes.

White Balance Auto

Red Offset 0

Blue Offset 65535

Parameter	Description
White Balance	• Auto/Auto 2: The device automatically adjusts the red and blue gains according to the lighting conditions. If there are still color casts in Auto mode, try Auto 2 mode. • Outdoor: Recommended for outdoor scenes where the color temperature varies widely. • Fine Tune: Allows user to manually adjust red and blue offsets. • Night Fine Tune: (At night) Manually adjust the Red and Blue offset values. • Sodium Lamp: Automatically adjust the red and blue gains for optimal color reproduction in sodium light sources. • Locked: Keep the current color temperature.
Red Offset	When White Balance is set to Fine Tune , drag the slider or set the value to adjust the red offset.
Blue Offset	When White Balance is set to Fine Tune , drag the slider or set the value to adjust the blue offset.

8. Go to the **Video Standard** tab to configure the parameters. You can click **Default** on the left to restore the default factory settings.

Video Standard: Used to be compatible with the video capture and display logic of traditional analog cameras and DVRs/NVRs.

- PAL: Uses 50Hz frame rate, focusing on color accuracy and stability, suitable for static/detail scenes.
- NTSC: Uses 60Hz frame rate, focusing on motion smoothness, suitable for fast action scenes.

Video Standard PAL ▼

9. Repeat the previous steps to complete all scene parameters and corresponding image settings.

7.5.1.2 Image Scene Switch

Select whether to add the scene to the auto switching list (include the default scene). When enabled, if the conditions for switching to a non-default scene are met, the camera will automatically switch to the scene; otherwise, the camera uses the default scene. When disabled, the camera uses the currently selected scene.



Note:

- If multiple non-default scenes meet the switching condition at the same time, the device will switch to the scene with the smallest number (starting from 1 to 5).
- When **Auto Switch** is enabled, all the scene parameters cannot be configured.
- When **Auto Switch** is enabled, the current scene will be automatically switched based on the settings.

1. Go to **Setup > Image > Image > Image Scene Switch**.

Enable Auto Switch ☐

Switch Mode Timed Switch

No.	Auto Switching	Schedule	Image Scene Name
1	Default Scene		1<Scene1>
2	☐	Start Time~End Time	2<Scene2>
3	☐	Start Time~End Time	3<Scene3>
4	☐	Start Time~End Time	4<Scene4>
5	☐	Start Time~End Time	5<Scene5>

Save

2. Enable **Enable Auto Switch**.
3. Click the ☐ before the scene to add it to the auto switching list.
4. Set the schedule. Up to 4 periods are allowed, and the periods must not overlap. If both the start time and end time are 0, the settings do not take effect.
5. Select the corresponding number for each scene to be enabled.
6. Click **Save**.

7.5.1.3 Engineering

Lens Initialization: Resets the lens motor to resolve image blurring caused by prolonged use of zoom and focus on the **Live View** page.

Go to **Setup > Image > Engineering**.



Reset Lens

Reset


7.5.2 OSD

See **Setup > Common > OSD**.

7.5.3 Privacy Mask

Privacy mask is used to cover certain areas on the image for privacy, for example, ATM keyboard. When a PTZ camera rotates and zooms, the privacy mask moves and zooms with the camera and the masked area is always covered.

1. Go to **Setup > Image > Privacy Mask**.



2. Click **Add** to add a privacy mask. The privacy mask is a rectangle by default.
3. Adjust the mask as needed.
 - To adjust the size and position of the area, point to a handle of the area and drag to resize it. Point to any position of the area and drag it to the desired position.
 - Click any position on the left live view page and drag to draw an area.

7.6 Video & Audio

7.6.1 Video

7.6.1.1 Video

1. Go to **Setup > Video & Audio > Video > Video**.

Capture Mode: 2688x1520@25

Main Stream

Video Compression: H.264 Resolution: 1920x1080(1080P) Frame Rate(fps): 25

Bit Rate(Kbps): 2048 Bitrate Type: VBR Image Quality: ☐ Bit Rate ☐ Quality

I Frame Interval: 5 GOP: IP Smoothing: Clear Smooth

Smart Encoding: Off

Sub Stream

Enable: ☒

Video Compression: H.264 Resolution: 1280x720(720P) Frame Rate(fps): 25

Bit Rate(Kbps): 2048 Bitrate Type: VBR Image Quality: ☐ Bit Rate ☐ Quality

I Frame Interval: 5 GOP: IP Smoothing: Clear Smooth

Third Stream

Enable: ☐

Save

2. Select a capture mode for your camera.

After you change the capture mode, the encoding settings will be reset to defaults and some models of cameras will restart.

3. Set stream parameters.

At present, up to 3 streams are supported for each channel, and the streams are independent of each other and can be set with different resolutions, frame rates, video compression formats, etc. Only the main stream supports full resolution.

Item	Description
Video Compression	Select a video compression standard for your camera: H.265 or H.264. The bit rate restores to the default when you switch between H.264 and H.265.
Resolution	Select a video resolution for your camera. The higher the resolution, the clearer the image.
Frame Rate(fps)	The number of frames per second. Choose a frame rate from the drop-down list.  Note: To ensure image quality, the frame rate shall not be greater than the reciprocal of the shutter speed.
Bit Rate(Kbps)	Set the bit rate. Range: 128 to 16384, integer only.  Note: The bitrate range may vary with camera model.
Bitrate Type	Select the bitrate type. • CBR: The device keeps a specific bit rate by varying the quality of video streams. • VBR: The device keeps the quality of video streams as constant as possible by varying the bit rate.
Image Quality	Adjust the image quality by dragging the slider. It is configurable when Bitrate Type is set to VBR . The closer the slider is to Quality , the higher the bit rate, and the higher the image quality. The closer the slider is to Bit Rate , the lower the bit rate, and the image quality will be affected.
I Frame Interval	Set the number of frames between I-frames. A shorter interval presents better image quality but consumes more bandwidth and storage.
GOP	Group of Pictures, defines the basic pattern of the video stream encoded with I and P frames.
Smoothing	Set the smoothness of the video stream. Drag the slider to choose whether smoothness or clarity takes precedence.  Note: Smoothing is recommended for fluent video in a poor network environment.
Smart Encoding	Select the smart encoding mode, including Off , Basic Mode , and Advanced Mode . • Basic Mode: The bit rate is reduced by about 25%. • Advanced Mode: The bit rate is reduced by about 50%.

4. (Optional) Set other streams as needed. To enable third stream, please enable sub stream first. Set stream parameters settings for details.
5. Click **Save**.

7.6.1.2 Image Encoding

Set the snapshot parameters, and then set the scheduled snapshot as needed.

1. Go to **Setup > Video & Audio > Video > Image Encoding**.

| Single Photo Resolution

Resolution

| Single Photo of Passing


Photo Size

2. Set the resolution and maximum photo size. The greater the value, the higher the image quality.
3. Click **Save**.

7.6.2 ROI


When enabled, the system ensures image quality for the specified areas on the image first at low bit rate.

1. Go to **Setup > Video & Audio > ROI**.



2. Set ROI areas.

(1) Click + to add an ROI area. The area is a rectangle by default. Up to 8 areas are allowed.



(2) Adjust the area as needed.

- To redraw the detection area, click on the image and drag to draw a new one.
- To adjust the size and position of the area, point to a handle of the area and drag to resize it. Point to any position of the area and drag it to the desired position.

7.6.3 Audio

7.6.3.1 Audio

1. Go to **Setup > Video & Audio > Audio > Audio**.

Audio Input

Audio Input ☒

Access Mode Line/Mic

Input Volume 50

Audio Compression G.711U

Sampling Rate(KHz) 8

Noise Suppression ☒

Audio Channel 1 Line ☒ Enable

Audio Output

Audio Output Line

Output Volume 95

Save

2. Set audio input parameters.

Item	Description
Audio Input	Enable Audio Input .  Note: If audio is not needed, it is recommended to turn it off to improve camera performance.
Access Mode	Select the audio input mode, including Line/Mic and RS485 . Some cameras connect to a sound pickup via a RS485 cable. You need to set the access mode to sound pickup.
Input Volume	Drag the slider or input a value to set the input volume.
Audio Compression	Choose the audio compression format: G.711U , G.711A , or AAC-LC .
Sampling Rate(kHz)	Choose a sampling rate: 8kHz and 16kHz . The higher the sampling rate, the better the sound quality.
Noise Suppression	Reduce noise in audio to improve audio output quality.
Audio Channel 1	Select the Enable checkbox to enable audio input for the channel.

3. Set audio output parameters.

Item	Description
Audio Output	A speaker or an earphone needs to be connected.
Output Volume	Drag the slider or input a value to set the output volume.

4. Click **Save**.

7.6.3.2 Audio File

Go to **Setup > Video & Audio > Audio > Audio File**.

 **Note:** Different device models support different features, and functions may vary.

Set Alarm Volume

Drag the slider or input a value to set alarm volume. After configuration, click **Save**.

Alarm Volume



95

Import Audio

PCM or MP3 files, each no more than 200K.

Click **Import** and select a file.

Alarm Audio File

Import

Note: PCM or MP3 files, each no more than 200K.

Audio Preview

Built-in warning tones. Click  to play the audio.

No.	Audio	Operation
1	Warning!	

7.6.4 Media Stream

7.6.4.1 Media Stream

Media streams are a type of media that transmit audio and video content in real-time via data streams. The media stream page displays third-party clients, such as PCs or other servers, that are currently receiving data transmitted from the camera. After the media stream is added, the camera can transmit the collected images, audio, or video to a designated IP address or port using the specific transmission protocol.

1. Go to **Setup > Video & Audio > Media Stream > Media Stream**.

No.	Stream Profile	Protocol	Destination IP	Destination Port	Persistent	Status	+
-----	----------------	----------	----------------	------------------	------------	--------	---

2. Click **+** to add a media stream.
3. Complete the media stream settings.

Item	Description
Stream Profile	Includes the main stream, sub stream, third stream, etc. Some models only involve the main stream. The device will transmit data captured under a specific stream profile to third-party systems.
Destination IP	Enter the IP address of the device receiving media streams.
Protocol	The default protocol is RTMP. The device transmits data to a third-party client through the specific protocol.
Persistent	Set whether to automatically establish the configured media stream after restart.

4. Click **OK**.

7.6.4.2 RTSP Multicast Address

RTSP multicast allows third-party players to request RTSP multicast media streams from the camera through the RTSP protocol.

1. Go to **Setup > Video & Audio > Media Stream > RTSP Multicast Address**.

| Main Stream

Multicast Address

0.0.0.0

Port

0

Save

2. Set the multicast address and port number (multicast address range: 224.0.1.0 to 239.255.255.255, port number range: 0 to 65535).
3. Click **Save**.

7.7 Event

7.7.1 Common Alarm

7.7.1.1 Motion Detection

Motion detection detects motions in specified grids on the image. An alarm is reported when detection rules are triggered.

1. Go to **Setup > Event > Common Alarm > Motion Detection**.

Motion Detection ☐

Rule Settings Trigger Actions Plan

Rule Mode ☒ Area ☐ Grid

Detection Rule + Rule1

Sensitivity 0

Object Size 1

Alarm Parameters

Suppress Al... 15

Save


2. Enable the function.
 3. Choose the rule mode.
 - Area Detection
- (1) Click + to add a detection rule. A default rectangle detection appears on the image. Up to 4 detection rules are allowed.



(2) Adjust the detection box as needed.

- To adjust the size and position of the area, point to a handle of the area and drag to resize it. Point to any position of the area and drag it to the desired position.
- Click anywhere on the image, and then drag to draw a new area.


(3) Set detection rules.

Item	Description
Sensitivity	Set the sensitivity by dragging the slider. The higher the sensitivity, the higher the detection rate, and the more likely false alarms will occur. Set based on the scene and your actual needs.
Object Size	Drag the slider to set object size. • The ratio of the size of the detected object to the size of the detection area. An alarm is triggered when the ratio reaches the set value. To detect motion of small objects, you need to draw a small detection area separately. • Motion detection results of the current detection area are shown below in real time. The red means motions that have triggered a motion detection alarm. The height of the lines indicates the extent of motion. The density of the lines indicates the frequency of motion. The higher a line, the greater the extent. The denser the lines, the higher the frequency. 

(4) Set alarm parameters. Set **Suppress Alarm** to avoid receiving the same alarms within a certain length of time (alarm suppression time). For example, alarm suppression time is set to 5s, after an alarm is reported:

- If no motion is detected within the next 5s, new alarms can be reported after 5s when the alarm suppression time (5s) is over.
- If motion is detected within the next 5s, the alarm suppression time recounts from the time of the last alarm, and new alarms can be reported when the alarm suppression time (5s) is over.

- Grid Detection



(1) Set grid detection areas.

(2) Adjust grid detection areas as needed.

- Click to clear the grid; or click and drag on grid areas to erase grids.
 - Redraw:
 - Click on a grid vertex and drag to clear grids.
 - Click to draw a grid ; click for multiple times to form irregular detection areas; or click and drag the draw the rectangle grid area.
- (3) Set the sensitivity and alarm parameters. See the description in area detection.
4. Enter the **Trigger Actions** page. Configure alarm actions triggered by the detection rule to alert user or the specified people.

Conventional	Alarm Output	Storage
☐ Upload to FTP ☐ Send E-mail	☐ A -> 1	☐ Recording Edge Storage ☐ Image Edge Storage

- Conventional Linkage: The channels through which alarm information can be sent after an alarm linkage is triggered.
 - Upload to FTP: Complete the FTP parameter configuration first.
 - Send Email: Complete the email settings in [E-mail](#) first.
 - Alarm Output: Connect the external alarm output devices, such as alarm lights and alarm bells, etc., to the camera's ALARM OUT interfaces. The camera triggers alarm output devices when an event occurs.
 A→1: A refers to the ALARM OUT interfaces on the camera, 1 means the first ALARM OUT interface. Likewise, A→2 means the second ALARM OUT interface on the camera. The number of ALARM OUT interfaces may vary with camera model. See the device datasheet for specifications.
 Please set [Alarm Output](#) first, and enable the alarm interface as needed.
 - Storage
 - Recording Edge Storage: When an alarm is triggered, the camera automatically saves recordings to the [preset path](#).
 - Image Edge Storage: When an alarm is triggered, the camera automatically saves images to the [preset path](#).
5. Enter the **Plan** page. The default arming schedule is 24/7. The following two ways are available.
- Use the blue and white grids
 Click **Unarmed**, and click on the blue time grids to disable arming.
 Click **Armed**, and click on the white time grids to enable arming.
 - Use the **Edit** button
 (1) Click **Edit**. The **Edit** page appears.

- (2) Set the time periods for the current day. Up to 4 time periods are allowed and periods cannot overlap.
 - (3) Repeat the above steps and complete the settings for other six days. To apply the current settings to other days, select the check box(es) for the days and then click **Copy**.
 - (4) Click **OK** to save the arming schedule; click **Cancel** to exit the arming schedule settings.
6. Click **Save**.

7.7.1.2 Tampering Alarm

The camera triggers a tampering alarm after the lens is blocked for a certain length of time.

1. Go to **Setup > Event > Common Alarm > Tampering Alarm**.

2. Enable the function.
3. Drag the slider to adjust the sensitivity. The higher the sensitivity level, the higher the detection rate, and the higher the false alarm rate. Set based on the scene and your actual needs.
4. Set the duration of lens blocking. The camera reports an alarm when the duration of lens blocking exceeds the set value.
5. Set the alarm-triggered actions and arming schedule. See [Motion Detection](#) for details.
6. Click **Save**.

7.7.1.3 List Linkage

If a vehicle belongs to a specified type, the corresponding alarm linkage is triggered.

1. Go to **Setup > Event > Common Alarm > List Linkage**.

Vehicle Type Allowlist Vehicle ▾

Enable ☐

Trigger Actions Plan

Conventional	Alarm Output
☐ Upload to FTP	☐ A -> 1
☐ Send E-mail	☐ Alarm Sound

Save

2. Select the vehicle type to detect, including allowlisted vehicle, blocklisted vehicle, temporary vehicle, and no-plate vehicle.
3. Enable the function.
4. Set the alarm-triggered actions and arming schedule. See [Motion Detection](#) for details.
5. Click **Save**.

7.7.1.4 Vehicle Reverse Detection

When a vehicle reverses out of the view, the corresponding alarm linkage is triggered.

1. Go to **Setup > Event > Common Alarm > Vehicle Reverse Detection**.

Enable ☐

Trigger Actions Plan

Conventional	Alarm Output
☐ Upload to FTP	☐ A -> 1
☐ Send E-mail	☐ Alarm Sound

Save

2. Enable the function.
3. Set the alarm-triggered actions and arming schedule. See [Motion Detection](#) for details.
4. Click **Save**.

7.7.1.5 Vehicle Overstay Detection

When a vehicle has not left the recognition area after the set time, an overstay alarm linkage is triggered; when the vehicle leaves the detection area, the overstay alarm cleared linkage is triggered.

1. Switch to the **Live View** page, and set the allowed overstay time in **Advanced** in the lower-right corner.
2. Go to **Setup > Event > Common Alarm > Vehicle Overstay Detection**.

Enable ☐

Trigger Actions

Plan

Conventional	Alarm Output
☐ Upload to FTP	☐ A -> 1
☐ Send E-mail	☐ Alarm Sound

Save

3. Enable the function.
4. Set the alarm-triggered actions and arming schedule. See [Motion Detection](#) for details.
5. Click **Save**.

7.7.1.6 Motor Vehicle Metadata

Each attribute group contains three categories: vehicle type, vehicle color, and license plate color. At least one option must be selected for each category. When the detected vehicle type, vehicle color, and license plate color all match the configured attributes, an alarm linkage is triggered.

Up to three attribute groups can be configured.

1. Go to **Setup > Event > Common Alarm > Motor Vehicle Metadata**.

Select Metadata G... Motor Vehicle Metad... ▾

Enable ☒

Rule Settings Trigger Actions Plan

☒ Vehicle Type

☐ Sedan ☐ Pickup ☐ SUV ☐ MPV ☐ Van ☐ Bus ☐ Truck ☒ Motorcyc 1

☒ Vehicle Color

☒ Black ☐ White ☐ Red ☐ Green ☐ Blue ☐ Yellow ☐ Purple ☐ Gray

☐ Orange ☐ Brown ☐ Pink ☐ Silver...

☒ Plate Color

☒ White ☐ Yellow ☐ Blue ☐ Black ☐ Green ☐ Red ☐ Yellow... ☐ Gradl...

Save

2. Select the attribute group to enable.
3. Enable the function.
4. On the **Rule Settings** tab, select the vehicle type, vehicle color, and license plate color.
5. Set the alarm-triggered actions and arming schedule. See [Motion Detection](#) for details.
6. Click **Save**.

7.7.1.7 Alarm Input

The corresponding actions will be triggered when the alarm input is detected.

1. Go to **Setup > Event > Common Alarm > Alarm Input**.

Select Alarm Alarm Input 1 ▾

Rule Settings Trigger Actions Plan

Alarm Name A1

Alarm Type N.O. ▾

Alarm Input ☒

Save

2. Choose an alarm input port from the drop-down list.

The number of alarm inputs available may vary with camera model. For example, if the camera has two alarm inputs on the tail cable, you can configure alarm input 1 and alarm input 2 separately.

3. Set alarm input parameters.

Item	Description
Alarm Name	Set as needed.
Alarm Type	Set the alarm type according to the alarm input device. • If the alarm input device is normally open (N.O.), choose N.C.. • If the alarm input device is normally closed (N.C.), choose N.O..
Alarm Input	Enable Alarm Input .

4. Drag the slider to adjust detection sensitivity. The higher the sensitivity, the higher the detection rate, and the more likely false alarms will occur. Set based on the scene and your actual needs.

- Set the alarm-triggered actions and arming schedule. See [Motion Detection](#) for details.
- Click **Save**.

7.7.1.8 Alarm Output

The corresponding actions will be triggered when the alarm output is detected.

- Go to **Setup > Event > Common Alarm > Alarm Output**.

Select Alarm Alarm Output 1

Rule Settings

Alarm Name A1

Default Status N.O.

Alarm Mode ☒ Custom Duration

Delay(ms) 1000

Save

- Choose an alarm output port from the drop-down list. The number of alarm outputs available may vary with camera model.
- Set alarm output parameters.

Item	Description
Alarm Name	The default name is the alarm output channel ID. You can rename it as needed.
Default Status	Choose the default status. The default is N.O. . - If the external alarm device is normally open (N.O.), choose N.O.. - If the external alarm device is normally closed (N.C.), choose N.C..
Delay(s)	The duration of alarm output after the alarm is triggered. Set it as needed.
Relay Mode	Choose the relay mode. The default is Monostable . Monostable: The circuit can only remain in one stable state. When a trigger pulse is applied, the circuit switches to another state, and then automatically switches back to the original stable state. The circuit will repeat the same actions when the next trigger pulse arrives. Bistable: The circuit can remain in two stable states. When a trigger pulse is applied, the circuit switches to another state, and remains in this state after the trigger pulse is removed. When the next trigger pulse is applied, the circuit switches back to the other stable state and remains in that state.  Note: Set relay mode to better adapt to third-party alarm devices such as alarm lights. Please set the relay mode according to the trigger mode of the third-party alarm device.

- Click **Save**.

7.8 Storage

After inserting a micro SD card and the camera connecting to the [Intelligent Platform](#), you can then configure whether to store images on the camera's memory card.

Go to **Setup > Storage**.

- The **Storage Medium** is **EMMC** by default, which stores images only.

Storage Medium Memory Card Format

Storage Medium S... Normal

Total Capacity 14 GB , Free Space 0 GB

Image Storage Info

Image Storage Mo... ☐ Store When Disconnected ☒ Real-time Store

- When a Micro SD card is inserted, the storage medium will switch to **Memory Card**, allowing the camera to store recordings and images. The images previously stored in EMMC are unavailable.

Storage Medium Memory Card Format

Storage Medium S... Normal

Total Capacity 14 GB , Free Space 0 GB

Allocate Capacity

Video(GB) 9 (The remaining capacity is used for image storage.)

Video Storage Info

Storage Policy ☒ Manual and Alarm Recording ☐ Alarm Recording Only

Stream Main Stream

When Storage Full ☒ Overwrite ☐ Stop

Image Storage Info

Image Storage Mo... ☐ Store When Disconnected ☒ Real-time Store

Configure the parameters, and click **Save**.

Parameter	Description
Storage Medium	It is EMMC by default and switches to Memory Card when a Micro SD card is inserted. Then, the eMMC becomes ineffective. - Format: Click to format the Micro SD card. - Storage Medium Status: Show the actual status of the memory card. - Total Capacity: Show the total capacity and remaining space of the memory card.
Allocate Capacity	Allocate video storage capacity without exceeding total available storage capacity. The remaining capacity after allocation is used for image storage.  Note: When the allocated storage capacity exceeds remaining capacity, some historical images will be deleted from the Micro SD card.
Video Storage Info	- Storage Policy - Manual and Alarm Recording: Store manual recordings and alarm recordings. - Alarm Recording Only: Store alarm recordings only. - Stream: Main Stream by default. You can switch it to the sub stream.

Parameter	Description
	- When Storage Full - Overwrite: When space is used up on the memory card, new data overwrites old data. - Stop: When space is used up on the memory card, the camera stops saving new data.
Image Storage Info	 Note: The following configurations apply only to the photo server 1. For the photo server 2, the image storage mode is Store When Disconnected by default. - Store When Disconnected: This mode is recommended. - Photo server offline: The images are stored on the Micro SD card. - Photo server online: The images are uploaded to the photo server without local storage on the Micro SD card. - Real-time Store: It requires significant storage space. - Photo server offline: The images are stored on the Micro SD card. - Photo server online: The images are uploaded to the photo server and will be also stored on the Micro SD card.

7.8.1 Storage

After inserting a micro SD card and the camera connecting to the [Intelligent Platform](#), you can then configure whether to store images on the camera's memory card.

Go to **Setup > Storage > Storage**.

- The **Storage Medium** is **EMMC** by default, which stores images only.

Storage Medium Memory Card Format

Storage Medium S... Normal

Total Capacity 14 GB , Free Space 0 GB

Image Storage Info

Image Storage Mo... ☐ Store When Disconnected ☒ Real-time Store

- When a Micro SD card is inserted, the storage medium will switch to **Memory Card**, allowing the camera to store recordings and images. The images previously stored in EMMC are unavailable.

Storage Medium Memory Card Format

Storage Medium S... Normal

Total Capacity 14 GB , Free Space 0 GB

Allocate Capacity

Video(GB) (The remaining capacity is used for image storage.)

Video Storage Info

Storage Policy ☒ Manual and Alarm Recording ☐ Alarm Recording Only

Stream Main Stream

When Storage Full ☒ Overwrite ☐ Stop

Image Storage Info

Image Storage Mo... ☐ Store When Disconnected ☒ Real-time Store

Configure the parameters, and click **Save**.

Parameter	Description
Storage Medium	It is EMMC by default and switches to Memory Card when a Micro SD card is inserted. Then, the eMMC becomes ineffective.

Parameter	Description
	- Format: Click to format the Micro SD card. - Storage Medium Status: Show the actual status of the memory card. - Total Capacity: Show the total capacity and remaining space of the memory card.
Allocate Capacity	Allocate video storage capacity without exceeding total available storage capacity. The remaining capacity after allocation is used for image storage.  Note: When the allocated storage capacity exceeds remaining capacity, some historical images will be deleted from the Micro SD card.
Video Storage Info	- Storage Policy - Manual and Alarm Recording: Store manual recordings and alarm recordings. - Alarm Recording Only: Store alarm recordings only. - Stream: Main Stream by default. You can switch it to the sub stream. - When Storage Full - Overwrite: When space is used up on the memory card, new data overwrites old data. - Stop: When space is used up on the memory card, the camera stops saving new data.
Image Storage Info	 Note: The following configurations apply only to the photo server 1. For the photo server 2, the image storage mode is Store When Disconnected by default. - Store When Disconnected: This mode is recommended. - Photo server offline: The images are stored on the Micro SD card. - Photo server online: The images are uploaded to the photo server without local storage on the Micro SD card. - Real-time Store: It requires significant storage space. - Photo server offline: The images are stored on the Micro SD card. - Photo server online: The images are uploaded to the photo server and will be also stored on the Micro SD card.

7.8.2 FTP

Upload images and videos to an FTP server for storage.

1. Go to **Setup > Storage > FTP**.

Server Parameters

Server IP Upload Images ☐

Port No. Upload Video ☐

Username Test

Password

Confirm

☒ Photo ☐ Recording

Save To:\

☒ File Path ☐ File Name

No.	Naming Element
1	Disable
2	Disable
3	Disable

2. Configure server parameters.

Item	Description
Server IP	IP address of the FTP server.
Port No.	The default is 21. You can set a different port as needed.
Username	Username used to log in to the FTP server.
Password	Password used to log in to the FTP server.
Upload Images	Select the checkbox if you want to upload common (non-smart) snapshots. To configure an FTP server for smart snapshots. Overwrite Storage: When the number of images in the folder of the lowest level reaches the threshold, the server continues to save new images by overwriting the existing images. For example, if the folder path is \IP\date, the level-2 folder "date" is the lowest. When the images uploaded on Jan. 4, 2026 reaches the limit, existing images in the 20260104 folder will be overwritten by new images.  Note: Overwrite storage requirement: Make sure the last naming element of filename is Photo No..
Upload Video	Select if you want to upload alarm-triggered recordings.
Test	Test the connection to the FTP server.

3. Configure the storage path.

Item	Description
Photo	File path, up to 6 levels. If not specified, the default path "\IP\Date \Common" will be used. Common means common snapshots.
	Filename, up to 20 fields are allowed. If not specified, the sequence number such as 1, 2, 3, ... will be used as the filename.
Recording	File path, up to 6 levels. If no path is specified, the default path "\IP\Date \Common" will be used.

- Click **Save**.

8 Maintenance

8.1 Maintenance

8.1.1 Maintenance



Note:

- Software upgrade, device restart, restoration to defaults, configuration import, or person library import will restart the camera.
- Restarting the camera will interrupt the ongoing services. Please handle with caution.

Go to **Maintenance > Maintenance > Maintenance**.

Software Upgrade

Local upgrade and cloud upgrade are available.

Software Upgrade

Local Upgrade ☐ Upgrade Boot Program

Cloud Upgrade

Note: The upgrade will take a while. Please do not disconnect power.



Note:

- Make sure the upgrade file matches the device; otherwise, unexpected problems may occur.
 - The version file is a .zip file that includes all the upgrade files.
 - Power must be connected throughout the upgrade.
- Local Upgrade
 - Click **Browse**, and locate the upgrade file.
(If applicable) select **Upgrade Boot Program** to upgrade the boot program.
 - Click **Upgrade**. The camera will restart automatically after the upgrade is completed and the login page will appear.
 - Cloud Upgrade: Click **Detect** to check for new versions. You can perform a cloud upgrade if a new version is available on the cloud server.

System Configuration

You can export the current configurations of the camera to the computer or an external storage device for backup, so when necessary, you can restore camera configurations by importing the backup file.

Config Management

Default ☐ Restore all settings to defaults without keeping current network and user settings.

Importing

Exporting

- Click **Default**, and the system will restore all settings to factory defaults except current network and user settings, and the camera will restart automatically.

When **Restore all settings to defaults without keeping current network and user settings** is enabled, the camera will reset to factory settings. If a Micro SD card is installed, its capacity allocation will restore to default settings, and any data may be cleared.
- Import Configuration

 **Note:** Before you import a configuration file, make sure the file matches the camera model; otherwise, unexpected results may occur.

1. Click **Browse**.
 2. Select the configuration data, and then click **Import**.
 3. Click **OK**. The camera will restart after importing the configuration file.
- Export Configuration: Click **Export**.

Diagnosis Info

You can export the image debugging information for troubleshooting.

Diagnosis Info

Export Diagnosis I...

Export

☒ Collect Image Debugging Info

Collect Image Debugging Info: Export the video and debugging information.

Device Restart

You can restart the camera either immediately or at the set time.

 **Note:** Restarting the camera will interrupt the ongoing services. Please handle with caution.

Device Restart

Restart device

Restart

Enable Auto Restart



OK

Note: 1. Software upgrade, device restart, restoration to defaults or configuration import will restart the device.
2. Restarting the device will interrupt the connection to the device.

- Restart immediately: Click **Restart**, and click **OK** to restart the camera.
- Restart automatically:
 1. Select **Enable Auto Restart**, and set the restart time.
 2. Click **OK**, and the camera will restart based on the set time.

8.1.2 Network Diagnosis

Go to **Maintenance > Maintenance > Network Diagnosis**.

Network Diagnosis

Network Diagnosis

Select NIC

NIC1 (10000000000000000000)

IP Filter

All

Port Filter

All

Custom Rules



Start Capture

1. Select an NIC.
2. Select an IP and port filter mode.
 - All: Capture packets of all the ports and IPs.

- Specify: Capture packets of the specified port and IP.
 - Filter: Capture packets except that of the specified port and IP.
3. (Optional) Set the custom rules according to description.
 4. Click **Start Capture** to start capturing packets.
 5. Click **Stop Capture**, and the captured data are saved to the custom directory.

Network Delay and Packet Loss Test

The system can send test packets multiple times, and check if the operation is normal and network is smooth based on average delay and packet loss, which can help users to find the cause of network failures. The average delay refers to the average length of time from test packets are sent till responses are received. The packet loss rate refers to the ratio of lost packets to the sent packets.

Network Delay and Packet Loss Test

Test Address

Packet Size (Bytes)

64

Test Result

Start Test

1. Enter the test address.
2. Enter the options based on instructions.
3. Click **Test**. The results will appear after the test is complete.