# Release Notes

# Release Notes

**Keywords:** Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for

GIPC-B6202.11.6.C00022.230802

#### Acronym:

Acronym	Full Name
IPC	IP Camra

# Content

1 Version Information	3
1.1 Version Number ·····	3
1.2 Release History	3
1.3 Version Mapping Table	3
2 Feature and Change Description	3
3 Version Upgrade Procedure ·····	3
3.1 Upgrade Overview ·····	3
3.1.1 Version Upgrade Environment·····	3
3.1.2 Version Upgrade Modes ·····	4
3.2 Upgrade Procedure ·····	4
3.2.1 Upgrade Through the Web	4

### 1 Version Information

#### 1.1 Version Number

GIPC-B6202.11.6.C00022.230802

### 1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
GIPC-B6202.11.6.C00022.230802	NA	2023-08-02	Initial release

### 1.3 Version Mapping Table

Table 2 Product models and corresponding versions

Product Series	IPC Series		
Series	IPC		
	IPC series:		
Models	IPC2124SR5-ADF28KM-G; IPC2124SR5-ADF40KM-G; IPC324SR3-DSF28KM-G;		
	IPC324SR3-DSF40KM-G; IPC3614SR3-ADF28KM-G; IPC3614SR3-ADF40KM-G;		
	IPC2125SR5-ADF28KM-G; IPC2125SR5-ADF40KM-G; IPC325SR3-ADF28KM-G;		
	IPC325SR3-ADF40KM-G; IPC3615SR3-ADF28KM-G; IPC3615SR3-ADF40KM-G;		
	IPC3614SR3-ADF28KM-G; IPC3615SR3-ADF28KM-G; IPC3614SR3-ADF28KM-G;		
	IPC324SR3-DSF28KM-G; IPC325SR3-ADF28KM-G; IPC2124SR5-ADF28KM-G;		
	IPC325SR3-ADF28KM-G; IPC2124SR5-ADF28KM-G		
Target file name	GIPC-B6202.11.6.C00022.230802.zip		

# 2 Feature and Change Description

None.


# 3 Version Upgrade Procedure

### 3.1 Upgrade Overview

#### 3.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.


#### 3.1.2 Version Upgrade Modes

You can upgrade through the Web.

### 3.2 Upgrade Procedure

#### 3.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.



- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC\_G6202-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.