OTS-B8601.2.1 Release Notes

Zhejiang Uniview Technologies Co., Ltd.

OTS-B8601.2.1 Release Notes

Keywords: Version information, usage notes, precautions.

Abstract: This document provides information about the **OTS-B8601.2.1** board software, including version information, usage notes, precautions, and features.

Acronym

Acronym	Full Name
IVT2600@A-A16S-OS	16-Channel Terminal Recording Host

2025-5-20 Page 1

Contents

1 Version Information	3
1.1 Version Number ·····	3
1.2 Applied Product Models ·····	3
1.3 Release History ·····	3
2 Usage Notes ·····	3
3 Software Features ·····	3
4 Version Change Description ·····	3
4.1 Feature Change Description ·····	3
4.2 Operation Change Description	3
4.3 Solved Issues ·····	3
5 Related Documents and Delivery Method·····	4
6 Version Upgrade Guidance ·····	4
6.1 Precautions·····	4
6.2 Upgrade Procedure ·····	4
6.3 Upgrade Through the Web Interface·····	4

1 Version Information

1.1 Version Number

OTS-B8601.2.1

1.2 Applied Product Models

Table 1 Applied Product Models

Product Models	Description	
IVT2600@A-A16S-OS	16-Channel Terminal Recording Host	

1.3 Release History

Table 2 Released Versions

Version No.	Basic Version No.	Released On	Remarks
OTS-B8601.2.1	OTS-B8601.1.0	2025-5-19	Initial release

2 Usage Notes

None.

3 Software Features

None

4 Version Change Description

4.1 Feature Change Description

None

4.2 Operation Change Description

None

4.3 Solved Issues

None

5 Related Documents and Delivery Method

Table 3 Related Document List

Manual Name	Manual Version	Delivery
Network Video Recorders Quick Guide	V1.00	Deliver with device.

6 Version Upgrade Guidance

6.1 Precautions

Maintain proper network connection and power supply during the upgrade.

6.2 Upgrade Procedure


The version can be upgraded through the Web interface.

6.3 Upgrade Through the Web Interface

Perform the following steps to upgrade through the Web interface:

- (1) Log in to the Web interface as "admin".
- (2) Click Maintenance > Maintenance > Upgrade.


Figure 1 System Maintenance



(3) Click **Browse** right to the **Upgrade** field, select the **Program.bin** file to upgrade, and then click **Upgrade**.

(4) If the NVR is connected to the public network, you may also click **Check** to perform a cloud upgrade. If a newer version is detected, a prompt message will appear. Click **OK** to start upgrade.

Figure 1 Prompt Message



(5) The NVR will restart automatically when the upgrade is completed.

Version Upgrade Disclaimer

- By setting or installing this program in any way you agree to all of the following terms and conditions. Your
 downloading or using the program means you acknowledge your full understanding and acceptance of the
 following terms and conditions. If you do not agree to any of the following terms, you shall not use the
 program and you must cease installing and delete the program immediately.
- 2. The upgrade program is only applicable to the intended regions and product models. Before upgrade or update, please read the release notes carefully to make sure the program is applicable to your region and product model. You will be fully liable and responsible for all the consequences of device abnormality and related maintenance costs caused by your improper operations.
- 3. Uniview owns or is legally authorized to own all rights and IPRs (Intellectual Property Rights) of the program and the supplied release notes.
- 4. Software upgrades are for the optimization of product functions and do not mean there is defect.
- 5. You must strictly follow instructions in the release notes during the upgrade process, otherwise you are responsible for the possible consequences and related maintenance costs.
- 6. You shall not engage in any of the following activities, otherwise you would be liable for infringement and

responsible for any adverse consequences arising therefrom.

- 6.1 Copy the program (exclude the reasonable and necessary copies for internal backups);
- 6.2 Exclude this statement when using the program or transfer the program to any third party;
- 6.3 Modify the program or its derivatives;
- 6.4 Reverse engineer, decompile or disassemble this program.
- 7. The program is only intended for authorized users. Its architecture, organization and source code are valuable trade secrets and confidential information owned by Uniview and its authorized parties. You agree not to provide or disclose any confidential information contained in or derived from the software to any third party. No part of this document may be excerpted, reproduced, or distributed in any form by any entity or individual without written consent from our company.