DIPC-B6108.1.68.240814

Release Notes

Zhejiang Uniview Technologies Co., Ltd

DIPC-B6108.1.68.240814

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for DIPC-B6108.1.68.240814.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information3
1.1 Version Number ······3
1.2 Release History ······3
1.3 Version Mapping Table
2 Feature Change Description3
3 Version Upgrade Description
4 Version Upgrade Procedure
4.1 Upgrade Overview······3
4.1.1 Version Upgrade Environment ······4
4.1.2 Version Upgrade Modes······4
4.2 Upgrade Procedure ······4
4.2.1 Upgrade Through the Web4
5 Version Upgrade Disclaimer 5

1 Version Information

1.1 Version Number

DIPC-B6108.1.68.240814

1.2 Release History

Table1Released versions

Version No.		Basic Version No.	Released On	Remarks
DIPC-B6108.1.68.240814	D	IPC-B6108.1.67.240704	2024-09-04	Improve release
Table2 Version mapping table				
Product Mapping Item		Version No. (For External)		
NVR		B3772.33.72.240122		

1.3 Version Mapping Table

Table3Product models and corresponding versions

Product Series	IPC Series		
Series	IPC2128LE、IPC328LE、IPC3618LE		
	IPC2128LE series: IPC2128LE-ADF28KM-H、IPC2128LE-ADF40KM-H、 IPC2128LE-ADF28KMC-DL、IPC2128LE-ADF40KMC-DL		
Models	IPC328LE series: IPC328LE-ADF28K-H、IPC328LE-ADF40K-H		
	IPC3618LE series: IPC3618LE-ADF28K-H、IPC3618LE-ADF40K-H、 IPC3618LE-ADF28KC-DL、IPC3618LE-ADF40KC-DL		
Target file name	DIPC-B6108.1.68.240814.zip		

2 Feature Change Description

None

3 Version Upgrade Description

None.


4 Version Upgrade Procedure

4.1 Upgrade Overview

4.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure1Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

4.1.2 Version Upgrade Modes

You can upgrade through the Web.

4.2 Upgrade Procedure

4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as admin (default password: 123456).
- (2) Click Setup>Maintenance>Device Maintenance. The Device Maintenance page is displayed.

Firmware Upgrade			
Upgrade File		Browse	Upgrade Upgrade Boot Program
Device Restart			
Restart	Restart the device.		
🗌 Enable Auto Restart	Each Day 02:00:00	ОК	
Config Management			
Default	Keep current network and user settings and restore other settings to defaults.		
Importing		Browse	Import
Exporting	C:\Users\Desktop\tftp	Browse	Export
Diagnosis Info			
Storage Path	C:\Users\MyLocalFiles\Debug\	Browse	Download

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_D6108-XXXXX.zip, and then click **Open.**
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.

(5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

5 Version Upgrade Disclaimer

- 1. By setting or installing this program in any way you agree to all of the following terms and conditions. Yourdownloading or using the program means you acknowledge your full understanding and acceptance of the following terms and conditions. If you do not agree to any of the following terms, you shall not use the program and you must cease installing and delete the program immediately.
- The upgrade program is only applicable to the intended regions and product models. Before upgrade or update, please read the release notes carefully to make sure the program is applicable to your region and product model. You will be fully liable and responsible for all the consequences of device abnormality and related maintenance costs caused by your improper operations.
- 3. Uniview ownsor is legally authorized toownall rights and IPRs (Intellectual Property Rights) of the program and the supplied releasenotes.
- 4. Software upgradesareforthe optimization of product functions and do not mean there is defect.
- 5. You must strictly follow instructions in the release notes during the upgrade process, otherwise you are responsible for the possible consequences and related maintenance costs.
- 6. You shall not engage in any of the following activities, otherwise you would be liable for infringement and responsible for any adverse consequences arising therefrom.
- 6.1 Copy the program (exclude the reasonable and necessary copies for internal backups);
- 6.2 Exclude this statement when using the program or transfer the program to any third party;
- 6.3 Modify the program or its derivatives;
- 6.4 Reverse engineer, decompile or disassemble this program.
- 7. The program is only intended for authorized users. Its architecture, organization and source code are valuable trade secrets and confidential information owned by Uniview and its authorized parties. You agree not to provide or disclose any confidential information contained in or derived from the software to any third party. No part of this document may be excerpted, reproduced, or distributed in any form by any entity or individual without written consent from our company.