


# Network Video Recorders

## Quick Guide



V2.00


# 1 Default

IP address: 192.168.1.30  
Username: admin  
Password: 123456


## NOTE!

For security, it's strongly recommended to change the default password into a strong password of at least nine characters including all three elements: digits, letters and special characters.

# 2 Indicators

	Indicator	Status	Description
RUN (operation)	Steady on	Device is operating properly.	
	Blinking	Device is starting up.	
ALM (alarm)	Steady on	Device alarm occurred.	
NET (network)	Steady on	Device is connected to network.	
HDD (hard disk)	Steady on	Hard disk is inserted and in position.	
HdN (hard disk)	Steady green	Hard disk status is normal, with no data reading or writing.	
	Blinking green	Hard disk status is normal, with data being read or written.	
	Steady yellow	Hard disk status is abnormal.	
	Blinking yellow	RAID is being rebuilt.	

## 3 Interfaces



Interface	Description	Interface	Description
1	Grounding	2	Alarm input/output
3	VGA output	4	RS232
5	HDMI output	6	eSATA
7	USB	8	10M/100M/1000M network port
9	Alarm input	10	Alarm output
11	RS485	12	12V power output
13	AC power module		

## 4 Installation

### 4.1 Preparation

- Prepare a 1# or 2# Philips screwdriver, a pair of antistatic gloves or a wrist strap.
- Disconnect power before installation.




#### **CAUTION!**


For NVR supports the face library function, the function may be unavailable if there are no disks in slot 1 and slot 2.

## 4.2 Install HDD


1. Fix the mounting brackets to the disk with screws (L for left and R for right).



2. Press the latches on both sides, and then remove the front panel.



3. Align the disk with the slot and push it gently until it clicks into place. Repeat this step to mount all the hard disks.



4. Replace the front panel back into position.


## 5 Startup and Shutdown

Make sure the cables are connected correctly and the device is grounded properly. Use a power supply that meets requirements.

## 5.1 Startup

Connect the device to power to start up the device.

## 5.2 Shutdown

Click  > **Shutdown** on the toolbar at the bottom of the preview window.



### **CAUTION!**

Do not disconnect power when the device is operating or shutting down.


## 6 Local Operations

### 6.1 Add IP Devices

Before you begin, make sure the cameras are connected to your NVR via network.

#### 6.1.1 Quick Add

Follow the wizard to Step 4. Select the devices you want to add in the discovered device list, and then click **Add**.



Wizard

1 Wizard 2 Time 3 TCP/IP 4 IP Camera

Auto Switch to H.265  
Auto Switch to Smart Enco...  Off

Basic  Advanced

Select	IP Addr	Status	Qty	Device Model	Protocol	Port	Manufacturer	Serial No.
<input type="checkbox"/>	192.168.1.101		1	IPC2445-1	ONVIF	80	UNI	210235C13
<input type="checkbox"/>	192.168.1.102		1	IPC21225	ONVIF	80	UNI	210235C13
<input type="checkbox"/>	192.168.1.103		1	IPC2221ER	ONVIF	80	BeS	210235C85
<input type="checkbox"/>	192.168.1.104		1	IPC2425-1	ONVIF	80	UNI	210235C23
<input type="checkbox"/>	192.168.1.105		1	IPC2321-1	ONVIF	80	BeS	210235C24

Discovered Device(s):14, Added Device(s):1

+ Add Search

Previous OK Exit

















## NOTE!


After the device is added, if a message appears in the preview window indicating incorrect username or password, click  in the window toolbar and enter the correct username and password.

### 6.1.2 Custom Add

1. Right-click in the preview window, click **Menu > Camera > Camera**.
2. Click **Custom Add**, enter the IP address and other required information.



Camera	IP Address	Status	Protocol	Model	Add/Del	Cam Config	Net Config	Details
D8(D8)	192.168.1.100		ONVIF	HC1219TC				
	192.168.1.101	—	ONVIF	IPC2445	+	—		
	192.168.1.102		ONVIF	IPC2122	+	—		
	192.168.1.103		ONVIF	IPC2221	+	—		

3. Check camera status. If  is lit, the camera is online; otherwise, place the mouse cursor on the icon to view the cause of error. Click the edit button to modify device information.



## NOTE!

- You can also click  to add a device.
- Click **Search Segment** to search for devices in a specified network segment.

### 6.2 Playback

In the preview window, right-click a channel and choose **Playback** to start playing the recording of the current day.



## NOTE!

- A 7\*24 recording schedule is enabled by default. You can change the recording time and type at **Menu > Storage > Recording**. To set a recording schedule manually, right-click and select **Menu > Storage > Recording** and then set recording type and time based on your needs.
- If you choose the Event type of recording, you need to enable the corresponding alarm function and configure alarm-triggered recording/snapshot first.

## 7 Web Login

Before you begin, check that your PC is connected to your device via network.

1. Open the browser on your PC, enter the IP address in the address bar, then press **Enter**. Install the plugin as prompted at first login. Close all your browsers during the installation.
2. On the login page, enter the correct username and password, then click **Login**.

# Disclaimer and Safety Warnings


## Copyright Statement


©2023-2024 Zhejiang Uniview Technologies Co., Ltd. All rights reserved.

No part of this manual may be copied, reproduced, translated or distributed in any form or by any means without prior consent in writing from Zhejiang Uniview Technologies Co., Ltd (referred to as Uniview or us hereafter).

The product described in this manual may contain proprietary software owned by Uniview and its possible licensors. Unless permitted by Uniview and its licensors, no one is allowed to copy, distribute, modify, abstract, decompile, disassemble, decrypt, reverse engineer, rent, transfer, or sublicense the software in any form or by any means.

## Trademark Acknowledgements

 are trademarks or registered trademarks of Uniview.

 The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

All other trademarks, products, services and companies in this manual or the product described in this manual are the property of their respective owners.

## Export Compliance Statement

Uniview complies with applicable export control laws and regulations worldwide, including that of the People's Republic of China and the United States, and abides by relevant regulations relating to the export, re-export and transfer of hardware, software and technology. Regarding the product described in this manual, Uniview asks you to fully understand and strictly abide by the applicable export laws and regulations worldwide.

## EU Authorised Representative

UNV Technology EUROPE B.V. Room 2945, 3rd Floor, Randstad 21-05 G, 1314 BD, Almere, Netherlands.

## Privacy Protection Reminder

Uniview complies with appropriate privacy protection laws and is committed to protecting user privacy. You may want to read our full privacy policy at our website and get to know the ways we process your personal information. Please be aware, using the product described in this manual may involve the collection of personal information such as face, fingerprint, license plate number, email, phone number, GPS. Please abide by your local laws and regulations while using the product.

## About This Manual



- This manual is intended for multiple product models, and the photos, illustrations, descriptions, etc. in this manual may be different from the actual appearances, functions, features, etc. of the product.
- This manual is intended for multiple software versions, and the illustrations and descriptions in this manual may be different from the actual GUI and functions of the software.
- Despite our best efforts, technical or typographical errors may exist in this manual. Uniview cannot be held responsible for any such errors and reserves the right to change the manual without prior notice.
- Users are fully responsible for the damages and losses that arise due to improper operation.
- Uniview reserves the right to change any information in this manual without any prior notice or indication. Due to such reasons as product version upgrade or regulatory requirement of relevant regions, this manual will be periodically updated.

## Disclaimer of Liability

- To the extent allowed by applicable law, in no event will Uniview be liable for any special, incidental, indirect, consequential damages, nor for any loss of profits, data, and documents.
- The product described in this manual is provided on an "as is" basis. Unless required by applicable law, this manual is only for informational purpose, and all statements, information, and recommendations in this manual are presented without warranty of any kind, expressed or implied, including, but not limited to, merchantability, satisfaction with quality, fitness for a particular purpose, and noninfringement.
- Users must assume total responsibility and all risks for connecting the product to the Internet, including, but not limited to, network attack, hacking, and virus. Uniview strongly recommends that users take all necessary measures to enhance the protection of network, device, data and personal information. Uniview disclaims any liability related thereto but will readily provide necessary security related support.
- To the extent not prohibited by applicable law, in no event will Uniview and its employees, licensors, subsidiary, affiliates be liable for results arising out of using or inability to use the product or service, including, not limited to, loss of profits and any other commercial damages or losses, loss of data, procurement of substitute goods or services; property damage, personal injury, business interruption, loss of business information, or any special, direct, indirect, incidental, consequential, pecuniary, coverage, exemplary, subsidiary losses, however caused and on any theory of liability, whether in contract, strict liability or tort (including negligence or otherwise) in any way out of the use of the product, even if Uniview has been advised of the possibility of such damages (other than as may be required by applicable law in cases involving personal injury, incidental or subsidiary damage).
- To the extent allowed by applicable law, in no event shall Uniview's total liability to you for all damages for the product described in this manual (other than as may be required by applicable law in cases involving personal injury) exceed the amount of money that you have paid for the product.

## Network Security

**Please take all necessary measures to enhance network security for your device.**

The following are necessary measures for the network security of your device:

- **Change default password and set strong password:** You are strongly recommended to change the default password after your first login and set a strong password of at least nine characters including all three elements: digits, letters and special characters.
- **Keep firmware up to date:** It is recommended that your device is always upgraded to the latest version for the latest functions and better security. Visit Uniview's official website or contact your local dealer for the latest firmware.

The following are recommendations for enhancing network security of your device:

- **Change password regularly:** Change your device password on a regular basis and keep the password safe. Make sure only the authorized user can log in to the device.
- **Enable HTTPS/SSL:** Use SSL certificate to encrypt HTTP communications and ensure data security.
- **Enable IP address filtering:** Allow access only from the specified IP addresses.
- **Minimum port mapping:** Configure your router or firewall to open a minimum set of ports to the WAN and keep only the necessary port mappings. Never set the device as the DMZ host or configure a full cone NAT.
- **Disable the automatic login and save password features:** If multiple users have access to your computer, it is recommended that you disable these features to prevent unauthorized access.
- **Choose username and password discretely:** Avoid using the username and password of your social media, bank, email account, etc, as the username and password of your device, in case your social media, bank and email account information is leaked.
- **Restrict user permissions:** If more than one user needs access to your system, make sure each user is granted only the necessary permissions.
- **Disable UPnP:** When UPnP is enabled, the router will automatically map internal ports, and the system will automatically forward port data, which results in the risks of data leakage. Therefore, it is recommended to disable UPnP if HTTP and TCP port mapping have been enabled manually on your router.
- **SNMP:** Disable SNMP if you do not use it. If you do use it, then SNMPv3 is recommended.
- **Multicast:** Multicast is intended to transmit video to multiple devices. If you do not use this function, it is recommended you disable multicast on your network.
- **Check logs:** Check your device logs regularly to detect unauthorized access or abnormal operations.
- **Physical protection:** Keep the device in a locked room or cabinet to prevent unauthorized physical access.
- **Isolate video surveillance network:** Isolating your video surveillance network with other service networks helps prevent unauthorized access to devices in your security system from other service networks.

### Learn More

You may also obtain security information under Security Response Center at Uniview's official website.

## Safety Warnings

The device must be installed, serviced and maintained by a trained professional with necessary safety knowledge and skills. Before you start using the device, please read through this guide carefully and make sure all applicable requirements are met to avoid danger and loss of property.

## Storage, Transportation, and Use

- Store or use the device in a proper environment that meets environmental requirements, including and not limited to, temperature, humidity, dust, corrosive gases, electromagnetic radiation, etc.
- Make sure the device is securely installed or placed on a flat surface to prevent falling.
- Unless otherwise specified, do not stack devices.
- Ensure good ventilation in the operating environment. Do not cover the vents on the device. Allow adequate space for ventilation.
- Protect the device from liquid of any kind.
- Make sure the power supply provides a stable voltage that meets the power requirements of the device. Make sure the power supply's output power exceeds the total maximum power of all the connected devices.
- Verify that the device is properly installed before connecting it to power.
- Do not remove the seal from the device body without consulting Uniview first. Do not attempt to service the product yourself. Contact a trained professional for maintenance.
- Always disconnect the device from power before attempting to move the device.
- Take proper waterproof measures in accordance with requirements before using the device outdoors.

## Power Requirements

- Install and use the device in strict accordance with your local electrical safety regulations.
- Use a UL certified power supply that meets LPS requirements if an adapter is used.
- Use the recommended cordset (power cord) in accordance with the specified ratings.
- Only use the power adapter supplied with your device.
- Use a mains socket outlet with a protective earthing (grounding) connection.
- Ground your device properly if the device is intended to be grounded.

## Battery Use Caution

- When battery is used, avoid:  
Extremely high or low temperature and air pressure during use, storage and transportation.  
Battery replacement.
- Use the battery properly. Improper use of the battery such as the following may cause risks of fire, explosion or leakage of flammable liquid or gas.  
Replace battery with an incorrect type;  
Dispose of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery;
- Dispose of the used battery according to your local regulations or the battery manufacturer's instructions.

## Avertissement de l'utilisation de la batterie

- Lorsque utiliser la batterie, évitez:  
Température et pression d'air extrêmement élevées ou basses pendant l'utilisation, le stockage et le transport.  
Remplacement de la batterie.
- Utilisez la batterie correctement. Mauvaise utilisation de la batterie comme celles mentionnées ici, peut entraîner des risques d'incendie, d'explosion ou de fuite liquide de gaz inflammables.  
Remplacer la batterie par un type incorrect;

Disposer d'une batterie dans le feu ou un four chaud, écraser mécaniquement ou couper la batterie;

- Disposer la batterie utilisée conformément à vos règlements locaux ou aux instructions du fabricant de la batterie.

## Regulatory Compliance

### FCC Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Visit [http://en.uniview.com/Support/Download\\_Center/Product\\_Installation/Declaration/](http://en.uniview.com/Support/Download_Center/Product_Installation/Declaration/) for SDoC.

**Caution:** The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

### LVD/EMC Directive



This product complies with the European Low Voltage Directive 2014/35/EU and EMC Directive 2014/30/EU.

### WEEE Directive-2012/19/EU



The product this manual refers to is covered by the Waste Electrical & Electronic Equipment (WEEE) Directive and must be disposed of in a responsible manner.

### Battery Regulation- (EU) 2023/1542



Battery in the product complies with the European Battery Regulation (EU) 2023/1542. For proper recycling, return the battery to your supplier or to a designated collection point.