

Release Notes

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for
DIPC-B1230.6.5.C00048.240826

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information	3
1.1 Version Number	3
1.2 Release History	3
1.3 Version Mapping Table.....	3
1.4 Feature and Change Description	3
2 Version Upgrade Procedure	3
2.1 Upgrade Overview.....	3
2.1.1 Version Upgrade Environment.....	3
2.2 Upgrade Procedure	4
2.2.1 Upgrade Through the Web	4

1 Version Information

1.1 Version Number

DIPC-B1230.6.5.C00048.240826

1.2 Release History

Table1Released versions

Version No.	Basic Version No.	Released On	Remarks
DIPC-B1230.6.5.C00048.240826	DIPC-B1230.6.5.C00025.240530	2024-08-29	Improved release

1.3 Version Mapping Table

Table2Product models and corresponding versions

Product Series	IPC Series
Series	IPC
Type	IPC Series: IPC2124LB-AF28K-DL、IPC2124LB-AF40K-DL、IPC3614LB-AF28K-DL
Target file name	DIPC-B1230.6.5.C00048.240826.zip

1.4 Feature and Change Description

None.


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup>Maintenance>Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade	
Upgrade File	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upgrade"/> <input type="checkbox"/> Upgrade Boot Program
Device Restart	
<input type="button" value="Restart"/>	Restart the device.
<input type="checkbox"/> Enable Auto Restart	<input type="text" value="Each Day"/> <input type="text" value="02:00:00"/> <input type="button" value="OK"/>
Config Management	
<input type="button" value="Default"/>	Keep current network and user settings and restore other settings to defaults.
Importing	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Import"/>
Exporting	<input type="text" value="C:\Users\Desktop\lftp"/> <input type="button" value="Browse..."/> <input type="button" value="Export"/>
Diagnosis Info	
Storage Path	<input type="text" value="C:\Users\MyLocalFiles\Debug\"/> <input type="button" value="Browse..."/> <input type="button" value="Download"/>

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_D1230-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.