


800W AC Power Module

PWR-800A-AC-NB



Specifications

Model	PWR-800A-AC-NB
Power	
Indicator light	<p>Output ON and OK : Green</p> <p>No AC power to all power supplies : OFF</p> <p>AC present/Only 12Vsb on (PS off) : 1Hz Blink Green (0.5s Off and 0.5s Green)</p> <p>Power supply warning events where the PSU continues to operate: AC/DC Voltage warning : 1Hz Blink Orange (0.5s Off and 0.5s Orange)</p> <p>AC cord unplugged or DC power lost; with a second power supply in parallels still with AC input power : Orange</p> <p>Power supply warning events where the PSU continues to operate: high temperature warning, Fan warning, Over current warning, OV warning : 1Hz Blink Orange (0.5s Off and 0.5s Orange)</p> <p>Power supply critical event causing a shutdown: UVP, OVP, OCP, OTP, Fan fault, short out : Orange</p> <p>When the power in cold redundant state : 1Hz Blink Green (0.5s Off and 0.5s Green) Power supply FW update mode : 2Hz Blink Green</p>
AC Input Voltage	90-264VAC
AC Input Frequency	47 ~63 Hz
AC Input current	100-240V/10A, 180-360V/10A
Power Working Temperature	-5°C ~ 70°C
Power Storage Temperature	-40°C ~ 70°C

Ordering Info

Product Model	Description
PWR-800A-AC-NB	800W AC Power Module

Zhejiang Uniview Technologies Co., Ltd.

No. 369, Xietong Road, Xixing Sub-district, Binjiang District, Hangzhou City, 310051, Zhejiang Province, China (Zhejiang) Pilot Free Trade Zone, China

Email: overseasbusiness@uniview.com; globalsupport@uniview.com

<http://www.uniview.com>

©2024 Zhejiang Uniview Technologies Co., Ltd. All rights reserved.

*Product specifications and availability are subject to change without notice.

*Despite our best efforts, technical or typographical errors may exist in this document. Uniview cannot be held responsible for any such errors and reserves the right to change the contents of this document without prior notice.