

DIPC-B1219.2.89.250416

Release Notes

Zhejiang Uniview Technologies Co., Ltd

DIPC-B1219.2.89.250416

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for DIPC-B1219.2.89.250416.

Acronym:

| Acronym | Full Name |
|---------|-----------|
| IPC | IP Camera |

Content

| | |
|--------------------------------------|----------|
| 1 Version Information | 3 |
| 1.1 Version Number | 3 |
| 1.2 Release History | 3 |
| 1.3 Version Mapping Table | 3 |
| 2 Feature Change Description | 4 |
| 3 Version Upgrade Description | 7 |
| 4 Version Upgrade Procedure | 7 |
| 4.1 Upgrade Overview | 7 |
| 4.1.1 Version Upgrade Environment | 7 |
| 4.1.2 Version Upgrade Modes | 7 |
| 4.2 Upgrade Procedure | 7 |
| 4.2.1 Upgrade Through the Web | 7 |
| 5 Version Upgrade Disclaimer | 8 |

1 Version Information

1.1 Version Number

DIPC-B1219.2.89.250416

1.2 Release History

Table1Released versions

| Version No. | Basic Version No. | Released On | Remarks |
|------------------------|------------------------|-------------|------------------|
| DIPC-B1219.2.89.250416 | DIPC-B1219.2.88.250318 | 2025-04-24 | Improved release |

Table2 Version mapping table

| Product Mapping Item | Version No. (For External) |
|----------------------|--------------------------------------|
| NVR | B3112.3.29.220818/B3772.29.73.220930 |

1.3 Version Mapping Table

Table3Product models and corresponding versions

| Product Series | IPC Series |
|----------------|---|
| Series | IPC322LB、IPC3612LB、IPC2122LB、IPC-B122、IPC-T122、IPC-D122、IPC-B124、IPC-T124、IPC-D124、IPC-B125、IPC-T125、IPC-D125、IPC-B222 |
| Models | IPC322LB series: IPC322LB-SF28-A、IPC322LB-SF40-A、IPC322LB-SBF28-A IPC3612LBseries: IPC3612LB-SF28-A、IPC3612LB-SF40-A、IPC3612LB-SBF28-A IPC2122LBseries: IPC2122LB-SF28-A、IPC2122LB-SF40-A、IPC2122LB-SBF40-A IPC-B122 series: IPC-B122-APF28-SC、IPC-B122-APF40-SC、IPC-B122-APF28、IPC-B122-APF40 IPC-T122 series: IPC-T122-APF28-SC、IPC-T122-APF40-SC、IPC-T122-APF28、IPC-T122-APF40 IPC-D122 series: IPC-D122-PF28-SC、IPC-D122-PF40-SC、IPC-D122-PF28、IPC-D122-PF40 IPC-B124 series: IPC-B124-APF28-SC、IPC-B124-APF40-SC IPC-T124 series: IPC-T124-APF28-SC、IPC-T124-APF40-S IPC-D124 series: |

| | |
|------------------|--|
| | IPC-D124-PF28-SC、IPC-D124-PF40-SC IPC-B125 series: IPC-B125-APF28-SC、IPC-B125-APF40-SC IPC-T125 series: IPC-T125-APF28-SC、IPC-T125-APF40-SC IPC-D125 series: IPC-D125-PF28-SC、IPC-D125-PF40-SC IPC-B222 series: IPC-B222-APF40 |
| Target file name | DIPC-B1219.2.89.250416.zip |

2 Feature Change Description

D2005SP88(DIPC-B1219.2.88.250318)

None

D2005SP87(DIPC-B1219.2.87.240726)

None

D2005SP80(DIPC-B1219.2.80.240402)

None

D2005SP78(DIPC-B1219.2.78.230816)

None

D2005SP77(DIPC-B1219.2.77.230621)

None

D2005SP75(DIPC-B1219.2.75.230515)

| Item | Feature | Description |
|----------------------|---------------------------------------|---|
| Newly added features | None | None |
| Improved features | The default enabled status of EZCloud | <p>1. After the user logs in to the device for the first time and changes the password, a page will be displayed. The page allows the user to enable/disable EZCloud and reminds the user of possible privacy risks.</p> <p>2. Added a message (Setup>Network>EZCloud) indicating possible privacy risks that may come with enabled EZCloud.</p> |
| | Linear Stripe Suppression | <p>1. Linear Stripe Suppression is added on the Image settings page on the device's web page. The allowed range is 1 to 9, and the default is 5.</p> <p>2. Linear Stripe Suppression can be configured when Exposure Mode is set to Indoor 50Hz or Indoor 60Hz; it cannot be configured when Exposure Mode is set to other values.</p> <p>3. Linear Stripe Suppression and Exposure Mode are mutually exclusive. When WDR is set to On or Auto, Linear Stripe Suppression is grayed out and cannot be configured.</p> |
| Deleted features | None | None |

D2005SP72(DIPC-B1219.2.72.230308)

None

D2005SP71(DIPC-B1219.2.71.230221)

None

D2005SP67(DIPC-B1219.2.67.221019)

None

D2005SP66(DIPC-B1219.2.66.220921)

None

D2005SP65(DIPC-B1219.2.65.220831)

None

D2005SP63(DIPC-B1219.2.63.220804)

| Item | Feature | Description |
|----------------------|---|---|
| Newly added features | Default EZCloud enablement | EZCloud is enabled by default. |
| | Changed path of password retrieval using EZView | Updated the path for retrieving device password using EZView. The new path is Me > General > Forget Device Password |
| Improved features | None | None |
| Deleted features | None | None |

D2005SP61(DIPC-B1219.2.61.220712)

None

D2005SP98(DIPC-B1219.1.98.220517)

| Item | Feature | Description |
|----------------------|-----------------------|---|
| Newly added features | New added models | IPC-B222-APF40 |
| | Mandatory information | By default, user must fill in his/her mobile phone number or email address when logging in to the Web interface for the first time. |
| Improved features | None | None |
| Deleted features | None | None |

3 Version Upgrade Description

None.


4 Version Upgrade Procedure

4.1 Upgrade Overview

4.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure1Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

4.1.2 Version Upgrade Modes

You can upgrade through the Web.

4.2 Upgrade Procedure

4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup>Maintenance>Device Maintenance**. The **Device Maintenance** page is displayed.

The screenshot shows a software interface with four main sections:

- Firmware Upgrade:** Contains an "Upgrade File" text box, a "Browse..." button, an "Upgrade" button, and an unchecked checkbox labeled "Upgrade Boot Program".
- Device Restart:** Contains a "Restart" button, the text "Restart the device.", an unchecked checkbox labeled "Enable Auto Restart", a dropdown menu set to "Each Day", a time input field set to "02:00:00", and an "OK" button.
- Config Management:** Contains a "Default" button, the text "Keep current network and user settings and restore other settings to defaults.", an "Importing" text box with a "Browse..." button and an "Import" button, and an "Exporting" text box with the value "C:\Users\Desktop\lftp" and "Browse..." and "Export" buttons.
- Diagnosis Info:** Contains a "Storage Path" text box with the value "C:\Users\MyLocalFiles\Debug\" and "Browse..." and "Download" buttons.

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_D1219-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

5 Version Upgrade Disclaimer

1. By setting or installing this program in any way you agree to all of the following terms and conditions. Your downloading or using the program means you acknowledge your full understanding and acceptance of the following terms and conditions. If you do not agree to any of the following terms, you shall not use the program and you must cease installing and delete the program immediately.
2. The upgrade program is only applicable to the intended regions and product models. Before upgrade or update, please read the release notes carefully to make sure the program is applicable to your region and product model. You will be fully liable and responsible for all the consequences of device abnormality and related maintenance costs caused by your improper operations.
3. Uniview owns or is legally authorized to own all rights and IPRs (Intellectual Property Rights) of the program and the supplied release notes.
4. Software upgrades are for the optimization of product functions and do not mean there is defect.
5. You must strictly follow instructions in the release notes during the upgrade process, otherwise you are responsible for the possible consequences and related maintenance costs.
6. You shall not engage in any of the following activities, otherwise you would be liable for infringement and responsible for any adverse consequences arising therefrom.

- 6.1 Copy the program (exclude the reasonable and necessary copies for internal backups);
 - 6.2 Exclude this statement when using the program or transfer the program to any third party;
 - 6.3 Modify the program or its derivatives;
 - 6.4 Reverse engineer, decompile or disassemble this program.
7. The program is only intended for authorized users. Its architecture, organization and source code are valuable trade secrets and confidential information owned by Uniview and its authorized parties. You agree not to provide or disclose any confidential information contained in or derived from the software to any third party. No part of this document may be excerpted, reproduced, or distributed in any form by any entity or individual without written consent from our company.